OPERATING MANUAL

ba75976e07 09/2021



pHotoFlex® Turb

LED FILTER PHOTOMETER WITH INTEGRATED TURBIDITY MEASUREMENT AND pH FUNCTION



a **xylem** brand

Copyright

© 2021 Xylem Analytics Germany GmbH Printed in Germany.

pHotoFlex[®] Turb - Contents

1 1.1 1.2 1.3 1.4 1.5 LabStation (optional) 10 2 Safety information 11 2.1 2.1.1 Safety information in the operating manual 11 2.1.2 Safety signs on the meter 11 Further documents providing safety information 11 2.1.3 2.2 2.2.1 Authorized use 12 2.2.2 Requirements for safe operation 12 2.2.3 Unauthorized use 12 3 Scope of delivery 13 3.1 3.2 General information 13 3.2.1 Inserting/exchanging the batteries 15 3.2.2 3.3 Initial commissioning 16 4 Switching on the meter 17 4.1 Inserting a cell 18 4.2 4.3 General operating principles 20 4.3.1 Operating modes 20 4.3.2 Navigation 21 Navigation example 1: Setting the language ... 22 4.3.3 4.3.4 Example 2 on navigation: Setting the date and time 4.3.5 System settings (System menu) 28 4.4 4.4.1 Measured value memory 29 4.4.2 4.4.3 4.4.4 4.5 4.5.1

	4.5.2	Settings for photometric measurements	33
	4.5.3	Measuring the concentration	33
	4.5.4	Blank value (reagent blank value)	
	4.5.5	Standard adjustment (user calibration)	38
	4.5.6	Absorbance / % Transmission, measuring	
	4.5.7	Zero adjustment	
	4.5.8	Programs	
	4.5.9	Analysis timer	
	4.5.10	Timer	
	4.5.11	Measuring diluted samples	
4.6	pH valu	ue / ORP voltage	46
	4.6.1	General information	
	4.6.2	Measuring the pH value	47
	4.6.3	Measuring the ORP	
	4.6.4	Settings for pH and ORP measurements	48
	4.6.5	Calibration	
	4.6.6	Carrying out the TEC and NIST/DIN calibration	52
4.7	Turbidit	ty	56
	4.7.1	General information	56
	4.7.2	Aligning and marking a cell	56
	4.7.3	Measuring the turbidity	
	4.7.4	Calibration	
4.8	Memor	у	62
	4.8.1	Storing measurement datasets	
	4.8.2	Filtering measurement datasets	
	4.8.3	Displaying measurement datasets	
	4.8.4	Output measurement datasets to the RS232	•
		interface	65
	4.8.5	Erasing stored measurement datasets	
4.9	Transm	nitting data	66
	4.9.1	Establishing the connection to a PC	
	4.9.2	Data transmission with the PC software	
		LS Data	67
	4.9.3	Data transmission with the Excel add-in	
		MultiLab [®] Importer	67
	4.9.4	Establishing the connection to a printer	
	4.9.5	Configuration for the data transmission to a termi	
		program	
	4.9.6	Transmitting data to a printer or terminal	
		program	70
	4.9.7	Examples of data transmitted (printer, terminal	
		program)	70
4.10	Reset		72
	4.10.1	Resetting the system settings	
	4.10.2	Resetting the photometry settings	
	4.10.3	Resetting the settings for pH measurements	

	4.11	Meter information 73		
		Software update		
	4.13	Administrating user-defined methods		
		4.13.1 Administrating user-defined programs with a terminal program		
5	Mair	laintenance, cleaning, disposal		
	5.1	Maintenance		
		5.1.1 Inserting/exchanging the batteries		
	5.2	Cleaning		
	0.2	5.2.1 Cleaning the cell shaft		
		5.2.2 Cleaning the cells 81		
	5.3	Packing		
	5.4	Disposal 81		
6	Wha	t to do if		
	6.1	General errors		
	6.2	Photometry		
	6.3	pH value / ORP voltage		
	6.4	Turbidity		
7	Tech	nnical data86		
	7.1	General data		
	7.2	Photometry		
	7.3	pH value / ORP voltage		
	7.4	Turbidity		
8	Acce	essories and options89		
	8.1	Accessories		
	~ ~	8.1.1 Connecting cable		
	8.2	Optional extensions of the pHotoFlex [®] Turb		
9	Lists	s92		
10	Inde	x		
11	Firm	ware update99		
12	App Turb	endix: vidity values under 1 FNU/NTU		

1 Overview


1.1 General features

The compact pHotoFlex[®] Turb handheld precision meter enables you to carry out the following measurements quickly and reliably:

- Photometric measurements
 - Concentration measurements (colorimetric measurements)
 - Absorbance measurements
 - Transmission measurements
- pH measurements
- Turbidity measurements.

The pHotoFlex[®] Turb handheld meter provides the maximum degree of ease of use, reliability and measuring certainty for all applications.

The proven MultiCal[®] calibration procedure supports you in calibrating for pH measurements, and the AutoRead function enables precise pH measurements.






If you need further information or application notes, you can obtain the following material from WTW:

- Application reports
- Primers
- Safety datasheets.

You will find information on available literature in the WTW catalog or on the Internet.



Key functions	— M — 5	 Select the measuring mode <m> (long keystroke):</m> <i>Photometry</i> <i>Turbidity</i> <i>pH & ORP</i> Select the measured parameter within a measuring mode <m> (short keystroke):</m> <i>pH & ORP</i>: <i>pH, ORP</i> <i>Photometry: Concentration, Absorbance, % Transmission</i> <i>Turbidity:</i> no measured parameters selectable
	CAL/ZERO 2	Start calibration (measuring modes <i>pH & ORP</i> , <i>Turbid-ity</i>) Start zero adjustment or blank value measurement us- ing the <i>Photometry</i> \ <i>Adjustment</i> menu (measuring mode, <i>Photometry</i>) <cal zero=""></cal>

1.2 Keypad

PROG 0	In the <i>Photometry</i> measuring mode: Select a program for concentration measurement <prog></prog>
START/ENTER	Open menus / confirm entries / start measurement <start enter=""></start>
MENU 7	Call up the <i>Configuration</i> menu (all settings are made here) < MENU >
FORM 4	In the <i>Photometry</i> measuring mode, measured param- eter, <i>Concentration</i> : Switch over between available citation forms <form></form>
UNIT 1	In the <i>Photometry</i> measuring mode, measured parameter, <i>Concentration</i> : Switch over between available units <unit></unit>
Ф	Switch the meter on or off < ON/OFF >
PRT 8	Output the display contents to the RS232 interface (e.g. print) <prt></prt>
STО 9	Open the <i>Store</i> menu: <sto></sto> Quick storing: 2 x <sto></sto>
6 A 3	Highlight menu items or selection; Set the values $< \blacktriangle >, < \nabla >$
ESC	Switch to the next higher menu level / cancel input < ESC >




Entering numerals with the number keys (see ENTERING NUMER-ALS WITH THE NUMBER KEYS, page 22).


1.3 Display

The graphic display shows all information of the current measurement in the measured value display. The illumination enables to read the display even in the dark.

Example



1.4 Socket field



1.5 LabStation (optional)

The LabStation, which is available as an accessory, enables you to use the $pHotoFlex^{\ensuremath{\mathbb{R}}}$ Turb conveniently in the laboratory (see LabStation operating manual).

Laboratory operation with the LabStation enables the following additional functions:

- With photometric measurements, the zero measurement is retained even after switching the pHotoFlex[®] Turb off and on again
- You can connect a barcode reader for the simplified calling up of programs
- The LSdata software included serves to easily enter user-defined programs
- Operation with power pack and battery pack (included in the scope of delivery of the LabStation). The accumulator pack in the pHotoFlex[®] Turb is automatically charged as soon as the meter is placed in the LabStation.

2 Safety

2.1 Safety information

2.1.1 Safety information in the operating manual

This operating manual provides important information on the safe operation of the meter. Read this operating manual thoroughly and make yourself familiar with the meter before putting it into operation or working with it. The operating manual must be kept in the vicinity of the meter so you can always find the information you need.

Important safety instructions are highlighted in this operating manual. They are indicated by the warning symbol (triangle) in the left column. The signal word (e.g. "CAUTION") indicates the level of danger:



WARNING

indicates a possibly dangerous situation that can lead to serious (irreversible) injury or death if the safety instruction is not followed.



CAUTION

indicates a possibly dangerous situation that can lead to slight (reversible) injury if the safety instruction is not followed.

NOTE

indicates a possibly dangerous situation where goods might be damaged if the actions mentioned are not taken.

2.1.2 Safety signs on the meter

Note all labels, information signs and safety symbols on the meter and in the battery compartment. A warning symbol (triangle) without text refers to safety information in this operating manual.

2.1.3 Further documents providing safety information

The following documents provide additional information, which you should observe for your safety when working with the measuring system:

- · Operating manuals of further accessories
- Safety datasheets of the test reagents for working with photometric test sets.

2.2 Safe operation



CAUTION Danger of eye damage by visible and invisible LED radiation. In the cell shaft of the pHotoFlex[®] Turb there are light emitting diodes (LEDs) of the 1M class. Do not look at the radiation using optical instruments. With normal, authorized use there is no hazard.

2.2.1 Authorized use

This meter is authorized exclusively for carrying out the following measurements in the laboratory:

- Analysis of substances in water and aqueous solutions using round cells
- Concentration measurement
- Absorbance and transmission measurement

Only the operation and running of the meter according to the instructions and technical specifications given in this operating manual is authorized (see chapter 7 TECHNICAL DATA).

Any other use is considered unauthorized.

2.2.2 Requirements for safe operation

Note the following points for safe operation:

- The meter may only be operated according to the authorized use specified above.
- The meter may only be supplied with power by the energy sources mentioned in this operating manual.
- The meter may only be operated under the environmental conditions mentioned in this operating manual.
- The meter may only be opened if this is explicitly described in this operating manual (example: Inserting the batteries).

2.2.3 Unauthorized use

The meter must not be put into operation if:

- it is visibly damaged (e.g. after being transported)
- it was stored under adverse conditions for a lengthy period of time (storing conditions, see chapter 7 TECHNICAL DATA).

3 Commissioning

3.1 Scope of delivery

- Handheld meter, pHotoFlex[®] Turb
- 4 batteries 1.5 V type AA (in the battery compartment)
- 1 empty cell 16 mm
- 2 empty cells 28 mm with label to mark the cell for turbidity measurements
- AMCO[®]-Clear turbidity standard
- Microfiber cloth to clean the meter
- Compact operating manual
- Overview of the keys / available programs
- CD-ROM with
 - Detailed operating manual
 - Photometry analysis manual with analysis specifications
 - Software to program user-defined methods
- Optional: LabStation with LSdata PC software, battery pack and universal power pack
- Optional: Battery pack (rechargeable)



The optional parts of the scope of delivery are available as accessories (see section 8.1).

3.2 Power supply

3.2.1 General information

You can operate the meter either with batteries, battery pack or a power pack. The power pack supplies the meter with low voltage (9 V DC). At the same time, the battery pack is charged. The battery pack is charged even while the meter is switched off.

The *LoBat* display indicator appears when the batteries or battery pack are nearly discharged.

Charging time of the battery pack

approx. 36 hours.



CAUTION Use original power packs only.

The line voltage at the operating site must lie within the input voltage range of the original power pack (see chapter 7 TECHNICAL DATA).



The battery pack should not be completely discharged. If you do not operate the instrument for a longer period of time you should charge the battery pack every six months.


Automatic switchoff function

Connecting the power pack (optional) The meter has an automatic switch-off function in order to save the batteries or battery pack (see section 4.4).

Display illumina-During operation with the batteries or battery pack the meter automatically tion switches off the display illumination if no key is pressed for 30 seconds. The illumination is switched on with the next keystroke again. The display illumination can also be switched off completely (see section 4.4.2).



The power pack and battery pack are available as accessories (see section 8.1).




- If necessary, replace the Euro plug (1) of the power pack (2) by the 1 country-specific plug suitable for your country.
- 2 Connect the plug (3) to the socket (4) of the measuring instrument.
- 3 Connect the power pack unit to an easily accessible mains socket.

3.2.2 Inserting/exchanging the batteries

NOTE

Make sure that the poles of the batteries are positioned correctly. The \pm signs on the batteries must correspond to the \pm signs in the battery compartment.



- 1 Open the battery compartment:
 - Unscrew the two screws (1) on the underside of the meter,
 - Remove the lid of the battery compartment (2).
- 2 If necessary, take four old batteries out of the battery compartment.
- 3 Insert four batteries (3) in the battery compartment.
- 4 Close the battery compartment and fix it with the screws.

3.3 Initial commissioning

Perform the following activities:

- For
 - Battery operation: Insert the batteries (see section 3.2.2)
 - Battery pack operation: Insert the battery pack (see section 5.1.2)
 - Line power operation and charging the battery pack: Connect the power pack (see section 3.2)
 - Operation with LabStation and battery pack: Insert the battery pack, connect the LabStation and insert the meter in the LabStation (see LabStation operating manual)
- Switch on the meter (see section 4.1)
- Set the language as necessary (see section 4.3.3)
- Set the date and time as necessary (see section 4.3.4)



When you set the language, date and time according to the mentioned sections of this operating manual you will quickly become familiar with the simple operation of the pHotoFlex[®] Turb.

4 Operation

4.1 Switching on the meter

Switching on

Press the **<ON/OFF>** key.

For 30 seconds, the *Start* menu appears with a selection of the measuring modes. The measuring mode last selected is highlighted.

The status line indicates the meter designation and the version number of the software.

Start		
Photometry		
Turbidity		
pH & ORP		
i pHotoFlex V0.24		

After a few seconds, the meter automatically switches to the measuring mode and measured parameter used last.

The measured value display appears (here, e.g. measuring mode *Photometry*).

Photometry \ Concentration		
i Select program with <prog></prog>		
	01.02.05 15:12	

Press **<M>** (long pressure) to switch to the measuring mode.

Press **<M>** (short pressure) to switch between different measuring parameters in the selected measuring mode.

Switching off Press the **<ON/OFF>** key.

Automatic switchoff function The meter has an automatic switch-off function in order to save the batteries or battery pack (see section 4.4). The automatic switchoff switches off the meter if no key is pressed for an adjustable period.

The automatic switch-off function is not active

- if the power is supplied by the power pack (optional),
- if the power is supplied by the LabStation (optional),
- if the *Timer* or *Analysis timer* function is on.

Display illumination with batterypowered operation During operation with batteries or battery pack the meter automatically switches off the display illumination if no key is pressed for 30 seconds. The illumination is switched on with the next keystroke again.

4.2 Inserting a cell

In order to be able to insert cells into the $pHotoFlex^{(\!\!R\!)}$ Turb, the cell shaft must be prepared for holding a cell.

- 1 Push the dust cover (1) upward. The cell shaft for 28 mm cells is open.
 - Insert a 28 mm cell (see below)
 - Insert a 16 mm cell (see page 19)



- Inserting a 28 mm cell
- 2 Insert the cell so that it is positioned on the bottom of the cell shaft.

The cell is ready to be measured.



3 For turbidity measurement: Align the cell (see section 4.7.2).

Inserting a 16 mm cell


1 Put the fold-out cell shaft (2) in an upright position until it locks into place.



2 Pull upwards the height adapter (3). The cell shaft is extended.



3 Open the external light cover (4) of the cell shaft.



- 4 Insert the 16 mm cell (marking points to the front) so that it is positioned on the bottom of the cell shaft.
- 5 Close the external light cover (4). The cell is ready to be measured.



For optimum measurement results, the cell must always be covered by the external light cover. Otherwise, the external light can falsify the measurement result.

4.3 General operating principles

This section contains basic information on the operation of the $pHotoFlex^{\ensuremath{\mathbb{R}}}$ Turb.

Operating elements, and section 1.3. display An overview of the operating elements and the display is given in section 1.2

Operating modes, navigation An overview of the operating modes of the pHotoFlex[®] Turb and the navigation through menus and functions can be found in section 4.3.1 and section 4.3.2.

4.3.1 Operating modes

The instrument has the following operating modes:

- <u>Measurement</u> The display indicates measurement data in the measured value display
- <u>Calibration</u>
 The display indicates a calibration process with calibration information, or a process to carry out a <u>zero adjustment</u>
- <u>Data transmission</u> The meter transmits measuring datasets or calibration records to the serial interface
- <u>Configuration</u>
 The display indicates a menu with further menus, settings and functions

4.3.2 Navigation

Measured value display In the measured value display, you can

- select a measuring mode with **<M>** (long pressure)
- select a measured parameter in the active measuring mode (e. g. pH <- > mV) with <M> (short pressure)
- open the menu with <MENU>
- switch to the superordinate *Start* menu with **<ESC>**.

Menus and dialogs The menus for settings and dialogs in procedures contain further subelements. The selection is done with the keys $< \Delta > < \nabla >$. The current selection is displayed inverse.

Menus

The name of the menu is displayed at the upper edge of the frame. Menus are opened by confirming with **START/ENTER>**. Example:

Configuration	
Photometry	
Turbidity	
pH & ORP	
System	
Info	

• <u>Settings</u>

Settings are indicated by a colon. The current setting is displayed on the right-hand side. With **<START/ENTER>**, the selection of the possible settings is opened. Subsequently, the setting can be changed with **<** > **<** > and **<START/ENTER>**.

Example:

System	1
Language:	Deutsch
Beep:	Off
Illumination:	On
Contrast:	48 %
Temperature unit:	°C
Switchoff time:	30 min

<u>Functions</u>

Functions are designated by the name of the function. They are immediately carried out when you confirm them with **START/ENTER>**. Example: display the *Calibr. record* function (in the *pH* & *ORP* / *Calibration* menu).

pH & ORP	
Calibr. record	
Calibr. type:	AutoCal
TEC	
Calibr. interval:	007 d
Unit for slope: mV/pł	
i 2.00 4.01 7.00 10.01	

Messages

Information or operating instructions are designated by the i symbol. They cannot be selected. Example:

pH & *ORP Buffer recognition TEC* ← The i indicates *Immerse sensor in buffer 1* The i indicates *Info* texts, e.g. *messages, notes or instruc tions Set temperature:* 25 °C *Continue*

The principles of navigation are explained in the two following sections by reference of examples:

- Setting the language (section 4.3.3)
- Setting the date and time (see section 4.3.4).

Entering numerals with the number keys

Keys with additional characters printed on (orange) are assigned doubly. In the input fields you can directly enter digits with the orange number keys (e.g. date and time). Complete entering a number with the key **<START/ENTER>**.

When entering numeric values with decimal separators (e.g. turbidity nominal values), pressing **START/ENTER>** for the first time will set the decimal separator. Pressing **START/ENTER>** for the second time will complete the entering of the numeric value. The numeric value is always displayed with decimal places and, if necessary, rounded.

4.3.3 Navigation example 1: Setting the language



The following example describes in the language of the country how to set the language. On delivery, English is set as the language in the pHotoFlex[®] Turb. During initial commissioning, you can set the language in the menu, *Configuration / System / Language*.

- In the measured value display:
 Open the *Configuration* menu with **<MENU>**.
 The instrument is in the configuration mode.
- 2 Select the System menu with <▲ > <▼ >.
 The current selection is displayed in reverse video.
- 3 Using **<START/ENTER>**, open the *System* menu.

System	
Language:	Deutsch
Store	
Display	
Reset	
Interface	
Continue	

- 4 Select the Language menu with <▲ > <▼ >.
 The current selection is displayed in reverse video.
- 5 Open the setting of the *Language* with **<START/ENTER>**.

System	
Language:	Deutsch
Store	
Display	
Reset	
Interface	
Continue	

- 6 Select the required language with $< \Delta > < \nabla >$.
- 7 Confirm the setting with **START/ENTER>**. The setting is active. The menu is displayed in the selected language.
- 8 To make further settings, switch to the next higher menu level with **<ESC>**.

or

Switch to the measured value display with **<M>** (short pressure). The instrument is in the measuring mode.

4.3.4 Example 2 on navigation: Setting the date and time

The meter has a clock with a date function. The date and time are indicated in the status line of the measured value display. When storing measured values and calibrating, the current date and time are automatically stored as well.

Numerals are generally entered via the number keys.

The correct setting of the date and time and date format is important for the following functions and displays:

- Current date and time
- Calibration date
- Identification of stored measured values.

Therefore, check the time at regular intervals.



After a fall of the supply voltage (empty batteries, empty battery pack), the date and time are reset to 01.01.2003 00, 00:00 hours.

Setting the date, time and date format The date format can be switched from the display of day, month, year (*dd.mm.yy*) to the display of month, day, year (*mm/dd/yy* or *mm.dd.yy*).

- In the measured value display:
 Open the *Configuration* menu with **<MENU>**.
 The instrument is in the configuration mode.
- 2 Select and confirm the System / Continue ... / Date/time menu with
 <▲ > <▼ > and <START/ENTER>.

Date/time	
Time:	14:53:40
Date:	30.10.03
Date format:	dd.mm.yy

3 Select and confirm the *Time* menu with $\langle \blacktriangle \rangle \langle \nabla \rangle$ and $\langle START/EN-TER \rangle$.

A display for the entry of numerals with the number keys opens up.



4 Enter the time using the number keys.The digit to be changed is displayed underlined.



In the case of wrong entries, you can cancel the procedure with **<ESC>**. After canceling with **<ESC>**, it is possible to enter all digits once

After canceling with **<ESC>**, it is possible to enter all digits once again. The new digits are only taken over by confirming with **<START/ENTER>**.

- 5 Confirm the setting with **<START/ENTER>**. The time is set.
- 6 Set the current *Date* as necessary. The setting is made similarly to that of the time.
- 7 Change the date format as necessary.
- 8 To make further settings, switch to the next higher menu level with **<ESC>**.

or

Switch to the measured value display with **<M>** (short pressure). The instrument is in the measuring mode.

4.3.5 Menu overview

Photometry	Meas. param.	Concentration		
		% Transmission		
		Absorbance		
	Programs			
	Dilution			
	Analysis timer	On		
		Off		
	Reset			
Turbidity	i No settings requ	uired!		
pH & ORP	Meas. param.	pН		
		ORP		
	Calibration	Calibr. record		
		Calibr. type	TEC	
			NIST/DIN	
		Calibr. interval	1 999 d	
		Unit for slope	mV/pH	
			%	
	Man. temperature	-20 +130 °C		
	Temperature unit	°C, °F		
	Reset			

(continued on next page)

System

Language	Deutsch English Français Español		
Measured value	Display		
memory	RS232 download		
	Data filter	Filter ID PROG Datum	
	Delete		
	i 4 of 1000 i occupied		
	i Filter. No filter		
Display	Illumination	Auto off On Off	
	Contrast	0 100 %	
	Brightness	0 100 %	
Reset			
Interface	Baud rate	1200, 2400, 4800, 9600, 19200	
	Output format	ASCII CSV	
Continue /	Time	hh:mm:ss	
Date/time	Date		
	Date format dd.mm.yy mm.dd.yy mm/dd/yy		
Continue / Switchoff time	10, 20, 30, 40, 50 min, 1, 2, 3, 4, 5, 10, 15, 20, 24 h	1	
Continue / Beep	On Off		

Info

4.4 System settings (System menu)

The following meter characteristics and general functions are in the menu *Configuration / System*:

- Language selection (*Language*)
- Memory- and database functions (*Store*)
- Display settings (*Display*)
- Restoring the basic settings (*Reset*)
- Configuration of the interface for PC/printer (*Interface*)
- Setting the date/time (Date/time)
- Setting the switch-off time (*Switchoff time*)
- Setting the keyboard sound (*Beep*)

Settings/functions The settings are in the menu, *Configuration / System*. Move to the *Configuration* menu with the **<MENU>** key.

Menu item	Setting	Explanation
Language	Deutsch English Français Español	Select the language (see section 4.3.3)
Store	Display RS232 down- load Data filter Delete	Memory- and database func- tions (see section 4.8.2)
Display	Illumination Contrast Brightness	Switch on/off the display illumi- nation (see section 4.4.2)
Reset	-	Reset the system settings to the delivery condition (see section 4.10.1).
Interface	Baud rate Output format	Baud rate of the data interface (see section 4.4.3)
Continue / Date/time	Time Date Date format	Time and date settings (see section 4.3.4)

Menu item	Setting	Explanation
Continue / Switchoff time	10, 20, 30, 40, 50 min, 1, 2, 3, 4, 5, 10, 15, 20, 24 h	The automatic switchoff func- tion switches the meter off if no entry is made for a specified pe- riod of time (<i>Switchoff time</i>). This conserves the batteries or the battery pack.
Continue / Beep	On Off	Switches on/off the beep on keystroke

4.4.1 Measured value memory

In the *Measured value memory* menu, you find functions to display and edit the stored measurement datasets:

- Show measurement datasets on the display (*Display*)
- Output measurement datasets to the RS232 interface (RS232 download)
- Define filter rules for the stored measurement datasets (Data filter)
- Erase all stored measurement datasets (Delete)
- Information on the number of occupied memory locations

The settings are in the menu, *Configuration / System / Measured value memory*. Move to the *Configuration* menu with the **<MENU>** key.

Settings/functions	Menu item	Setting/ function	Explanation
	Display	-	Displays in pages all measurement data- sets that correspond to the filter settings.
			Further options:
			 Scroll through the datasets with <▼ >.
			 Output the displayed dataset to the inter- face with <prt>.</prt>
			 Quit the display with <esc>.</esc>
	RS232 down- load	-	Downloads to the interface all measure- ment datasets that correspond to the filter settings. The download is ordered accord- ing to the date and time.
			The process can take several minutes. To terminate the process prematurely, press <esc></esc> .

Menu item	Setting/ function	Explanation
Data filter	see section 4.8.2	Allows to set filter criteria in order to display and download datasets to the interface.
Delete	-	Erases the entire contents of the measuring data memory, independent of the filter set- tings.
		Note:
		All calibration data remain stored when this action is performed.

All details on the subjects of memory and stored data are given in section 4.8.2.

4.4.2 Display

In the Configuration / System / Display menu, you set the display features:

- Switching on/off the display illumination (*Illumination*)
- Display contrast (*Contrast*)

The settings are in the menu, *Configuration / System / Display*. Move to the *Configuration* menu with the **<MENU>** key.

Settings	Menu item	Setting	Explanation
	Illumination	Auto off	The display illumination switches itself off if no key has been pressed for 30 seconds.
		On Off	Switches the display illumination on or off permanently (see section 4.5.9)
	Contrast	0 100 %	Changes the display contrast
	Brightness	0 100 %	Changes the display brightness

4.4.3 Interface

In the Interface menu, you set the features of the interface.

- Transmission speed (Baud rate)
- Output format (Output format)

Settings	Menu item	Setting	Explanation
	Baud rate	1200, 2400, 4800, 9600, 19200	Baud rate of the data interface
	Output format	ASCII CSV	Output format for data transmission For details, see section 4.9

The settings are in the menu, *Configuration / System / Interface*. Move to the *Configuration* menu with the **<MENU>** key.

4.4.4 Date/time

In the *Configuration / System / Continue ... / Date/time* menu, you set the system clock:

- Current time (*Time*)
- Current date (*Date*)
- Format of the date display (Date format)

The settings are in the menu, *Configuration / System / Continue ... / Date/ time*.

Move to the *Configuration* menu with the **<MENU>** key.

Settings	Menu item	Setting	Explanation
	Time	hh:mm:ss	Enter the time with the number keys
	Date		Enter the date with the number keys
	Date format	dd.mm.yy mm.dd.yy mm/dd/yy	Settings of time and date.

4.5 Photometry

4.5.1 General information

Photometric measurements serve to determine chemical substances in liquid samples. For this determination, the substance to be determined has to be present in a form that is suitable for photometric measurement. At the same time, possible disturbing factors have to be excluded.

Before measurement, the sample has to be pretreated in order to bring the

substance to be determined into the form that is suitable for measurement and at the same time exclude disturbing factors.

Pretreatment of the sample is described in the analysis specification.

In a simple case, pretreatment can be to dissolve a solid substance in water; it can, however, also include chemical conversions, e. g. a digestion.

The chemicals required in the analysis specification are available as test sets.



Suitable analysis specifications for test sets can be found in the photometry analysis manual (on CD-ROM).

There you will also find further instructions on handling chemicals and on how to proceed when applying the analysis specifications.

Methods and the corresponding method data for many test sets are stored as programs in the pHotoFlex[®] Turb. A program number is assigned to each program.

The stored method data are loaded when the program number is entered or read in with the aid of a bar code reader.

You can look up an overview of the available methods in the photometry analysis manual and display it on the screen of the pHotoFlex[®] Turb (see section 4.5.8).

You can measure the following parameters with the pHotoFlex[®] Turb:

- Concentration [mg/l]
- % Transmission []
- Absorbance []

Preparatory Perform the following preparatory activities when you want to measure: **activities**

- Clean the exterior of the cells before filling them with sample and also before measuring if necessary (see section 5.2.2).
 The cells must be absolutely clean and free of scratches.
- 2 For measurement, place the pHotoFlex[®] Turb on a horizontal surface.

4.5.2 Settings for photometric measurements

For photometric measurements, the following settings are available in the *Configuration / Photometry* menu:

- Setting the measured parameter
- Displaying a list of all programs
- Setting the dilution factor
- Switching on or off the analysis timer
- Resetting the settings for photometric measurements

The settings are in the menu, *Configuration / Photometry*. Move to the *Configuration* menu with the **<MENU>** key.

Settings	Menu item	Setting	Explanation
	Meas. param.	Concentration % Transmission Absorbance	Measured parameters in mea- suring mode <i>Photometry</i>
	Programs		Display all programs with the corresponding program data (see section 4.5.8).
	Dilution		Set the dilution factor (see section 4.5.11)
	Analysis timer	On Off	Switch on/off the analysis timer (see section 4.5.9)
	Reset		Reset all settings for the <i>Pho-tometry</i> measuring mode (see section 4.10.3)

4.5.3 Measuring the concentration

- 1 Press the **<M>** key (long pressure) repeatedly until the *Photometry* measuring mode is selected.
- 2 Press the **<M>** key (short pressure) repeatedly until the measured parameter, *Concentration* is selected.

Second and all further

concentration measurements

First concentration measurement with the pHotoFlex[®] Turb

Photometry \ Concentration	Photometry \ Conc	entration
i Select program with <prog></prog>	i Select program with <prog> or with ▲ ▼ 83: A6/25 MC</prog>	NH4-N
	16 mm	0.20 - 6.51 mg/l
01.02.05 15:12		01.02.05 15:12



From the second concentration measurement, the data of the program last used is automatically displayed here.

With $< \Delta > < \nabla >$ you can quickly switch between the ten programs last used.

To select a program, you can as an alternative also read in the program number of an analysis specification with a bar code reader (see section 8.2). The following step three is skipped. You can directly start measuring.

The program number of the test is given in the analysis specification, in the list of available programs and, with some tests, on the packing of the test (under the bar code).

3 Open the *Program number* display with **<PROG>**, enter the required program number with the number keys and confirm with **<START/ENTER>**.

or (from the second concentration measurement):

Select a program out of the last ten programs with $< \Delta > < \nabla >$. The program data is displayed.




If a program number is selected that requires a measured blank value, the menu automatically guides to the blank value measurement.

Photometry \ Concentration		
i Insert sample		
i Start measure	ement	
with <start></start>	>	
83: A6/25 MC	NH4-N	
16 mm	0.20 - 6.51 mg/l	
	01.02.05 15:12	

4 Insert the cell (see section 4.2).

5 Start the measurement with **<START/ENTER>**.


Measurement is started. The result is displayed.




Display when the		
measuring range		
is exceeded or		
undercut		

Display	Meaning
"< [Lower limit of measuring	Measuring range undercut.
range]"	<u>Remedy:</u> Select a test with a lower
instead of the measured value	measuring range
"> [Upper limit of measuring	Measuring range exceeded.
range]"	<u>Remedy:</u> Select a test with a higher
instead of the measured value	measuring range or dilute the sample
Orientation value	This value serves as an indication for the selection of a suitable test or dilu- tion. If an evaluation of the measurement signal is no longer possible (intensity too high or too low), four bars appear ("").

Examples:







The orientation value can be very inaccurate and should not be used as a measured value!

4.5.4 Blank value (reagent blank value)

A blank value is required for every concentration measurement. For some programs (methods) for concentration measurement, the blank values are already stored in the meter. They are used automatically. For all other programs, the blank value has to be determined separately before the first measurement.

Each stored reagent blank value can be replaced by a blank value determined by the user.



You will find more information on blank values in the photometry analysis manual. A table with the programs and required blank values is included in the analysis specifications.

A blank value is always stored for the program that has just been called up. It remains stored until it is erased (menu item, *Delete blank value*) or over-written.

The *Reset* function erases all blank values measured by the user and restores the blank values stored in the factory.

If a blank value measured by the user is stored for a program, this blank value is used for measurement. The usage of the blank value measured by the user is documented and also indicated in the measured value display.

Blank value measurement

- 1 Press the **<M>** key (long pressure) repeatedly until the *Photometry* measuring mode is selected.
- 2 Press the **<M>** key (short pressure) repeatedly until the measured parameter, *Concentration* is selected.
- 3 Select a program with **<PROG>** as necessary.



The following measurement of the blank value applies only to the selected program. If no program is selected, the information i *No program selected.* appears on the display.

4 Open the adjustment menu with **<CAL/ZERO>**.

Photometry \ Adjustment
Zero adjust.
Measure blank value
Delete blank value

5 Using **<**▲ **> <**▼ **>** and **<START/ENTER>**, select and start the *Measure blank value* function.


The menu-guided blank value measurement begins. Follow the instructions on the display.

Measure blank value	
i 83: A6/25 MC	
<i>Cell</i> i = 16 mm	
i Insert blank sample	
Start measurement	

- 6 Insert a cell with blank sample (see section 4.2).
- 7 Start the measurement of the blank value with **<START/ENTER>**.

After measuring, the result of the blank value measurement is displayed and stored.

The result is displayed as i Blank value measurement successful! or i Blank value measurement erroneous!



8 Confirm the result with **<START/ENTER>**.

The blank value measurement is completed. The meter is ready to measure.

or:

Discard the result with <ESC>.

Subsequently, carry out a new blank value measurement.

4.5.5 Standard adjustment (user calibration)

With some of the programs (methods) for concentration measurement, you can optimize the calibration curve stored in the meter with the aid of the *Stan-dard adjustment* function.

A standard adjustment is only valid if the deviation compared to the original calibration is no more than 30%.

A standard adjustment is always stored for the program that is presently called up. A standard adjustment is only deleted if

- a new standard adjustment is carried out
- the standard adjustment is erased manually
- the meter is reset to delivery status (*Reset* function)


Standard adjustment

- 1 If necessary, press the **<M>** key several times until the measured parameter *Concentration* is selected.
- 2 Select a program with **<PROG>** as necessary.



The following measurement of the standard applies only to the selected program.

3 Open the *Photometry* \ *Adjustment* menu with **<CAL/ZERO>**.



4 Open the *Standard adjustment* menu with <▲ > <▼ > and <**START**/ **ENTER**>.



If data of a standard adjustment are already available, the data of the last standard adjustment are displayed. Here you can also erase the data of an active standard adjustment.

5 Using $\langle A \rangle \langle \nabla \rangle$ and $\langle START/ENTER \rangle$, select and start the *Measure standard* function.

The menu-guided standard measurement begins. Follow the instructions on the display.


Enter nominal value	
mg/l Cu	
_	

6 Enter the nominal value of the standard. Note:

Enter the decimal separator with <START/ENTER>.

- 7 Confirm the entered nominal value with **<START/ENTER>**.
- 8 Insert a cell with standard (see section 4.2).
- 9 Start the measurement of the standard with **START/ENTER>**. After measuring, the result of the standard adjustment is displayed and stored. As the result, the measured value and the adjustment (in %) or *Error*

As the result, the measured value and the adjustment (in %) or Error is displayed.



10 Confirm the result with **<START/ENTER>**.

The standard adjustment is completed. The meter is ready to measure.

or:

Discard the result with **<ESC>**.

Subsequently, carry out a new standard adjustment.



If a standard adjustment is stored for a program, the standard adjustment is automatically used for measurement. The usage of the standard adjustment is documented together with the measured value and indicated in the measured value display with [Cal].

4.5.6 Absorbance / % Transmission, measuring



The transmission measurement is not described separately in the following example as it operates in exactly the same way as the absorbance measurement. The result of the measurement is displayed in *% Transmission*.

- 1 Press the **<M>** key (long pressure) repeatedly until the *Photometry* measuring mode is selected.
- 2 Press the **<M>** key (short pressure) repeatedly until the measured variable, *Absorbance* or *% Transmission* is selected.

Photometry \ Abs	orbance
i Select cell	
with 🔺 🔻	
16 mm	610 nm
	01.02.05 15:12

- 3 Select the cell diameter with $\langle \blacktriangle \rangle \langle \nabla \rangle$ and confirm with $\langle START / ENTER \rangle$.
- 4 Select the wavelength with $\langle A \rangle \langle \nabla \rangle$ and confirm with $\langle START/EN-TER \rangle$.

Photometry \ Absorbance		
i Insert sample		
i Start measurement		
with <start></start>		
16 mm	610 nm	
	01.02.05 15:12	

- 5 Clean the cell (see section 5.2.2).
- 6 Insert the cell (see section 4.2).
- 7 Start the measurement with **START/ENTER>**. The measurement result is displayed when the measurement is finished.

Photometry \ Absorbance		
0.532		
16 mm	610 nm 01.02.05 15:12	

4.5.7 Zero adjustment

The zero adjustment, i. e. measuring and storing the absorbance of a cell filled with water, is necessary after the meter is switched on.

Additionally, we recommend to carry out a zero adjustment if the ambient temperature has changed.

Only perform the zero adjustment against distilled water in an optically perfect cell. The zero adjustment must be performed separately for each cell type.

- 1 Press the **<M>** key (long pressure) repeatedly until the *Photometry* measuring mode is selected.
- 2 Press the **<M>** key (short pressure) repeatedly until the measured parameter, *Concentration* is selected.
- 3 Press the **<CAL/ZERO>** key.

The menu for adjustment measurements opens up.

Photometry \ Adjustment
Zero adjust.
Measure blank value
Delete blank value

4 Using **<**▲ **> <**▼ **>** and **<START/ENTER>**, select and start the *Zero adjust.* function.

The menu-guided zero adjustment starts. Follow the instructions on the display.

Zero adjust.	
i Insert zero	
cell (dist. water)	
Cell	16 mm
Start measurement	

- 5 Insert the cell (see section 4.2).
- 6 Set another cell with $< > < \lor >$ and < START/ENTER> as necessary.
- 7 Start the measurement of the zero adjustment with **START/EN-TER>**.

After measuring, the result of the zero adjustment is displayed and stored.

i *Zero adjust. successful!* (successful zero adjustment) or i *Calibration error!* (zero adjustment not successful) is displayed as the result. The zero adjustment is completed.



If i *Calibration error!* was displayed as the calibration result, a note automatically reminds you of another zero adjustment before the next measurement.

Measuring is not possible without a valid zero adjustment.


8 Confirm the result with **<START/ENTER>**. The zero adjustment is completed. The meter is ready to measure.

4.5.8 Programs

Displaying program data

You can view the most important data of all methods. The method data is ordered according to the program number.

1 Open the menu *Configuration/ Photometry / Programs*. The display shows the most important data of the selected program.





This data is also to be found in the photometry analysis manual in the overview of the test sets and in the individual analysis specifications for the test sets.

Updating programs

Go to <u>www.WTW.com</u> to always find the latest software version with the newest programs and method data for your pHotoFlex[®] Turb (see FIRMWARE UP-DATE).

User-defined programs User-defined programs (methods) can be stored under program numbers between 900 and 999. You can store up to 100 user-defined programs (see section 4.13).

4.5.9 Analysis timer

Measuring according to analysis instructions often means there are waiting periods between the individual steps.

These waiting periods (time intervals) are stored in the instrument with the

program data for each program. The active *Analysis timer* function automatically reminds you to observe these time intervals by means of the menu guidance.

If you want to manually enter time intervals, use the *Timer* function (see section 4.5.10).

The *Analysis timer* with the required time interval is automatically displayed at the due point.

Start the *Analysis timer* with the **<START/ENTER>** key. Shortening the time interval is not possible. An acoustic signal sounds when the adjusted time interval has expired.

The Analysis timer function is switched on or off in the Configuration / Photometry/Analysis timer menu.

This setting generally applies to all measurements with methods according to analysis specification.

4.5.10 Timer

When measuring according to analysis specifications, waiting periods often have to be kept between individual steps of the method. With the *Timer* function you manually set a time interval.

If you want to be automatically reminded of the given time intervals, use the *Analysis timer* function (see section 4.5.9).

The timer is displayed in the measured value display. It always displays the remaining time of the adjusted time interval.

When the adjusted time interval has expired, the timer indicates 00:00:00, and an acoustic signal sounds.

The *Timer* function is started in the *Configuration / Timer* menu by entering a time interval.

4.5.11 Measuring diluted samples

If the concentration of a test sample exceeds the measuring range of a method, you can dilute the sample by a factor 1 ... 99 so that the concentration of the diluted test sample is within the measuring range of the method (see photometry analysis manual). Thus a valid measurement is possible.

After entering the factor for the dilution the meter converts the concentration to that of the undiluted sample.

The display then indicates the measured value of the undiluted sample.

Entering the factor of the dilution

1 Select the program for which a dilution factor is to be entered.

2 Open the menu *Configuration/ Photometry / Dilution*. The current factor of the dilution is displayed.

Г	_ Dilution	
V	/ater + sample	0 + 1
i	83: A6/25 MC	

- 3 Open the display for the entry of numerals with **START/ENTER>**.
- 4 Enter the factor of the dilution with the number keys. The factor has to be a whole number between 0 ... 99.
- 5 Confirm the factor with **<START/ENTER>**.
- 6 Exit the *Dilution* menu with **<ESC>**.

For the following measurements with the selected program, the concentration of the undiluted sampled is displayed as the measurement result.

The entered dilution factor is only valid for the selected program. The dilution factor is erased if

- the photometer is switched off
- a different program number is selected
- the factor 0 is entered in the *Dilution* menu.

If a dilution factor is active, it is indicated on the display during measurement in the form [x + 1].

4.6 pH value / ORP voltage

4.6.1 **General information**

You can measure the following parameters:

- pH value []
- ORP [mV]



The RS232 interface is not galvanically isolated.

When connecting an earthed PC/printer, measurements cannot be performed in earthed media as incorrect values would result!

Temperature measurement For reproducible pH measurements, it is essential to measure the temperature of the test sample.

You have the following options to measure the temperature:

- Automatic measurement of the temperature by a temperature sensor (NTC30 or Pt1000) integrated in electrode.
- Manual determination and input of the temperature.

The measuring instrument recognizes whether a suitable electrode is connected and automatically switches on the temperature measurement.

The display of the temperature indicates the active temperature measuring mode:

Temperature sensor	Resolution of the temp. display	Temperature of the measuring medium
yes	0.1 °C	Automatic measurement
-	1 °C	Manual measurement and entry

Preparatory activities

Perform the following preparatory activities when you want to measure:

1 Connect a pH or ORP electrode to the meter.

- 2 Press the **<M>** key (long pressure) repeatedly until the *pH* & *ORP* measuring mode is selected.
- 3 Press the **<M>** key (short pressure) repeatedly until the measured parameter, pH or ORP is selected.
- 4 Adjust the temperature of the solutions and measure the current temperature if the measurement is made without a temperature sensor.
- 5 Calibrate or check the meter with the electrode.

4.6.2 Measuring the pH value

- 1 Perform the preparatory activities according to section 4.6.1.
- 2 Immerse the pH electrode in the test sample.

рН & (ORP∖pH
	6.94
	25.0°C
[AR]	
	01.02.05 15:12

3 Press the **<M>** key (short pressure) repeatedly until the measured parameter pH is selected.

AutoRead (drift control) The AutoRead function (drift control) continually checks the stability of the measurement signal. The stability has a considerable impact on the reproducibility of measured values. The display of the measured parameter flashes until a stable measured value is available.

Criteria With identical measurement conditions, the following applies:

Measured parameter	Reproducibility	Response time
pH value	Better than 0.01	> 30 seconds

4.6.3 Measuring the ORP



ORP electrodes are not calibrated. However, you can check ORP electrodes using a test solution.

- 1 Perform the preparatory activities according to section 4.6.1.
- 2 Immerse the ORP electrode in the test sample.

рН & C	DRP\ ORP
	157 _{mV} 25.0 ℃
[AR]	
	01.02.05 15:12

	3 Press the <m></m> key (short pressure) repeatedly until the measured parameter, ORP is selected.
Read (drift	The AutoRead function (drift control) continually checks the stability of the

- AutoRead (drift control) The AutoRead function (drift control) continually checks the stability of the measurement signal. The stability has a considerable impact on the reproducibility of measured values. The display of the measured parameter flashes until a stable measured value is available.
 - **Criteria** With identical measurement conditions, the following applies:

Measured parame- ter	Reproducibility	Response time
ORP	better than 1 mV	> 30 seconds

4.6.4 Settings for pH and ORP measurements

Overview For pH and ORP measurements, the following settings are possible in the menu *Configuration / pH & ORP*:

- Meas. param.
- Calibr. record (display, print)
- Select the calibration type
- Enter the Calibr. interval
- Select Unit for slope
- Select Temperature unit
- Reset

Settings/functions The settings are in the menu, *Configuration | pH & ORP*. Move to the *Configuration* menu with the **<MENU>** key.

Menu item	Possible setting	Explanation
Meas. param.	<i>pH</i> & ORP mV	
Calibration / Calibr. record	-	Display the calibration record of the last calibration.
Calibration / Calibr. type	TEC NIST/DIN	Buffer sets to be used for pH cal- ibration. For details, see section 4.6.5.

Menu item	Possible setting	Explanation
Calibration / Calibr. interval	1 999 d	<i>Calibr. interval</i> for the pH elec- trode (in days).
		The meter reminds you to cali- brate regularly by the flashing sensor symbol in the measured value display.
Calibration /	mV/pH	Unit of the slope.
Unit for slope	%	The % display refers to the Nernst slope of -59.16 mV/pH (100 x determined slope/Nernst slope).
Man. temperature	-20 +130 °C	Entry of the manually determined temperature. For measurements without temperature sensor only.
Temperature unit	°C, °F	Degrees Celsius Degrees Fahrenheit
Reset		Reset all settings for the <i>pH</i> & <i>ORP</i> measuring mode (see section 4.10.3)

4.6.5 Calibration

Why calibrate?	pH electrodes age. This changes the asymmetry (zero point) and slope of the pH electrode. As a result, an inexact measured value is displayed. Calibration determines the current values of the asymmetry and slope of the electrode and stores them in the measuring instrument. Thus, you should calibrate at regular intervals.
When to calibrate?	 After connecting another combination electrode When the sensor symbol flashes: After the calibration interval has expired after voltage interruption (e.g. empty batteries, empty accumulator pack)
Buffer sets for cali- bration	You can use the buffer sets quoted in the table for an automatic calibration. The pH values are valid for the specified temperature values. The tempera-

Buffer set	Name on the dis- play	pH values at 25 °C
WTW Technical buffer	TEC	2.00
solutions		4.01
		7.00
		10.01
NIST/DIN buffer solu-	NIST/DIN	1.679
tions		4.006
		6.865
		9.180
		12.454

ture dependence of the pH values is taken into account during calibration.



The buffers are selected in the menu *Configuration / pH & ORP / Calibr. type*, see section 4.6.4).

Calibration points Calibration can be performed using one, two or three buffer solutions in any order (single-point, two-point or three-point calibration). The meter determines the following values and calculates the calibration line as follows:

	Determined val- ues	Displayed calibration data
1-point	Asy	• Asymmetry = <i>Asy</i>
		 Slope = Nernst slope (-59.16 mV/pH at 25 °C)
2-point	Asy	• Asymmetry = <i>Asy</i>
	Slp.	• Slope = <i>Slp</i> .
3-point	Asy	• Asymmetry = <i>Asy</i>
	Slp.	• Slope = <i>Slp.</i>
		The calibration line is calculated by lin- ear regression.



You can display the slope in the units, mV/pH or % (see section 4.6.4).

AutoRead

ad In calibration, the AutoRead function is automatically activated. The current AutoRead measurement can be terminated at any time (accepting the current value). **Calibration record** When finishing a calibration, the new calibration values are displayed as an informative message (symbol i) first. You can then decide whether to take over these values for the new calibration or to go on using the old calibration data. After the new calibration values have been taken over the calibration record is displayed.

Display calibra-
tion data and out-
put to interfaceYou can view the data of the last calibration on the display. Using the <PRT>
key, you can then download the displayed calibration data to the interface, e.
g. to a printer or PC.

The calibration record of the last calibration is to be found under the menu item, *Configuration / pH & ORP / CalibrationCalibr. record.*

Sample record

Calibration pl	r. no. 12345678 H & ORP 1.10.03 16:13:		
Buffer 1 Buffer 2 Buffer 3	4.01 7.00 10.01		
Voltage 1 Voltage 2 Voltage 3 Slope Asymmetry Sensor +++	184.0 mV 3.0 mV -177.0 mV -60.2 mV/pH 4.0 mV		

Calibration evaluation

After calibrating, the meter automatically evaluates the calibration. The asymmetry and slope are evaluated separately. The worse evaluation of both is taken into account. The evaluation appears on the display and in the calibration record.

Display	Calibration record	Asymmetry [mV]	Slope [mV/pH]
Ĩ	+++	-15 +15	-60,558
Ţ	++	-20 +20	-5857
T	+	-25 +25	-6160.5 or -5756

Display	Calibration record	Asymmetry [mV]	Slope [mV/pH]
	- ctrode according to operating manual	-30 +30	-6261 or -5650
		< -30 or > 30	62 or 50
	elimination accord- 6 WHAT TO DO IF		

Preparatory activities Perform the following preparatory activities when you want to calibrate:

- Connect the pH electrode to the meter.
 The pH measured value is shown on the display.
- 2 Keep the buffer solutions ready. Adjust the temperature of the buffer solutions, or measure the current temperature, if you measure without a temperature sensor.

4.6.6 Carrying out the TEC and NIST/DIN calibration

The two calibration procedures only differ in the use of different buffer sets (see section 4.6.5). Make sure that, in the *pH* & *ORP* / *Calibration* menu, the *Calibr. type* is correctly set (see section 4.6.4).

For this procedure, use any two or three WTW Technical buffer solution in ascending or descending order.

Below, the *TEC* calibration is described. With *NIST/DIN* calibration, the *NIST/DIN* buffer recognition and other buffer nominal values are displayed. Apart from that, the procedure is identical.



The TEC calibration at pH 10.01 is optimized for the WTW Technical buffer solution TEP 10 Trace or TPL 10 Trace. Other buffer solutions could cause the calibration to be erroneous. The correct buffer solutions are available in the WTW catalog or on the Internet.

1 Press the **<M>** key (short pressure) repeatedly until the measured parameter, *pH* or *ORP* is selected.

2 Start the calibration with **<CAL/ZERO>**. The calibration display appears.

pH & ORP \ Calibration	
i Buffer recognition TEC	
i Immerse sensor in buffer 1	
Continue	
Continue	


- 3 Immerse the electrode in buffer solution 1.
- 4 If the Set temperature menu item appears, measure and enter the temperature of the buffer manually (measurement without temperature sensor).
- 5 Using $\langle A \rangle \langle \nabla \rangle$ > *Continue*, highlight and press $\langle START/ENTER \rangle$. The buffer is measured.

The measured value is checked for stability (AutoRead).

	– pH & ORP \ Calibration	
i	Buffer value = 7.00	
i	U = 3 mV	
i	<i>Temperature</i> = 24.8°C	
1	erminate AutoRead	

6 Wait for the end of the AutoRead measurement or accept the calibration value with **<START/ENTER>**.

The calibration display for the next buffer appears.



7 Single-point calibration: Using $\langle \blacktriangle \rangle \langle \nabla \rangle$, select *Exit with one point calibr.* and confirm with \langle **START/ENTER** \rangle .

The calibration is completed as a single-point calibration.

The new calibration values are displayed as a piece of information (i).

You have the following options:

- Using **<START/ENTER>**, take over the new calibration values. Subsequently, the calibration record is displayed and output to the interface at the same time.
- Using **<M>** (short pressure) or **<ESC>** switch to the measured value display, <u>without</u> taking over the new calibration values.



For **single-point calibration**, the instrument uses the Nernst slope (-59.16 mV/pH at 25 $^{\circ}$ C) and determines the asymmetry of the electrode.


Continuing for two-point calibration (*Calibr. type TEC*)

- 8 Thoroughly rinse the electrode with distilled water.
- 9 Immerse the electrode in buffer solution 2.
- 10 If the *Set temperature* menu item appears, measure and enter the temperature of the buffer manually (measurement without temperature sensor).
- 11 Using $\langle A \rangle \langle \nabla \rangle$ > *Continue*, highlight and press $\langle START/ENTER \rangle$. The buffer is measured.

The measured value is checked for stability (AutoRead).

	pH & ORP \ Calibration	
i	Buffer value = 10.01	
i	U = -177 mV	
i	Temperature = 24.8°C	
T	erminate AutoRead	

12 Wait for the end of the AutoRead measurement or and accept the calibration value with **<START/ENTER>** *Terminate AutoRead*. The calibration display for the next buffer appears.



13 For two-point calibration, select with $\langle A \rangle \langle \nabla \rangle$ *Exit with 2 point calibr.* and confirm with $\langle START/ENTER \rangle$.

The calibration is completed as a two-point calibration.

The new calibration values are displayed as a piece of information (i).

You have the following options:

- Using **START/ENTER>**, take over the new calibration values. Subsequently, the calibration record is displayed and output to the interface at the same time.
- Using **<M>** (short pressure) or **<ESC>**, switch to the measured value display, <u>without</u> taking over the new calibration values.
- 14 Thoroughly rinse the electrode with distilled water.
- 15 Immerse the electrode in buffer solution 3.
- 16 If necessary, measure the temperature of buffer 3 manually and, using <▲ > <▼ > and <START/ENTER>, enter and confirm in the Set temperature setting.
- 17 Using $\langle A \rangle \langle \nabla \rangle$ > *Continue*, highlight and press $\langle START/ENTER \rangle$. The buffer is measured.

The measured value is checked for stability (AutoRead).

ľ	pH & ORP \ Calibration	
i	Buffer value = 4.01	
i	U = 184 mV	
i	<i>Temperature</i> = 24.8°C	
_		
T	erminate AutoRead	

Continuing with three-point calibration (Calibr. type TEC) 18 Wait for the end of the AutoRead measurement or *Terminate Auto-Read* and accept the calibration value with **<START/ENTER>**.

The new calibration values are displayed as a piece of information (i).

You have the following options:

- Using **<START/ENTER>**, take over the new calibration values. Subsequently, the calibration record is displayed and output to the interface at the same time.
- Using **<M>** (short pressure) or **<ESC>** switch to the measured value display, <u>without</u> taking over the new calibration values.

4.7 Turbidity

4.7.1 General information

Venting the sample Air bubbles in the sample affect the measuring result to a massive extent because they have a large scattering effect on the incident light. Larger air bubbles cause sudden changes in the measured values whereas smaller air bubbles are recorded by the instrument as turbidity. Therefore, avoid or remove air bubbles:

• During sampling, ensure all movement is kept to a minimum

• If necessary, vent the sample (ultrasonic baths, heating or adding a surface-active substance to reduce the surface tension)



To measure turbidity values under 1 FNU/NTU, please heed appendix 2 on page 101 additionally.

4.7.2 Aligning and marking a cell

Even completely clean quality cells exhibit tiny directional differences in their light transmittance. Therefore, for accurate and reproducible measurement results, it is necessary to always align both the sample cells and the cells for calibration standards in the same way (see section 2130 of the "Standard Methods for the Examination of Water and Wastewater", 19th issue). To do so, the optimum alignment of the cell is determined.



Never apply oily liquids to "smooth" any scratches (not even socalled "special silicone oils"). They unnecessarily contaminate the meter and your working environment. Measurement accuracy is ensured by aligning the cells. Scratched cells have to be replaced.

Avoiding or removing air bubbles Aligning a cell

- 1 Press the **<M>** key (long pressure) repeatedly until the *Turbidity* measuring mode is selected.
- 2 Clean the cell (see section 5.2.2).
- 3 Insert the cell (see section 4.2).
- 4 Align the cell:
 - Press and keep the **<START/ENTER>** key depressed.
 - Slowly rotate the cell once completely in small steps (by 360 °). After each step, wait briefly until the displayed measured value is stable.
 - Turn the cell back to the position with the lowest measured value.

1	

To keep the drift as low as possible, the time for aligning the cell while the **START/ENTER>** key is pressed is limited to 30 seconds. After this time, the meter starts the measurement automatically.

5 Release the **<START/ENTER>** key.

Measurement starts. The measured value is displayed.

Marking a cell In order to quickly bring a cell into the optimum alignment, it is helpful to mark the optimum alignment of the cell once it has been determined. This shortens every measurement or calibration with this cell considerably.

The marking can be made, for example, on a label on the cap of the cell.

6 Mark the optimum alignment of the cell. The cell is prepared for the shortened measuring or calibration procedures.

4.7.3 Measuring the turbidity



CAUTION Never pour any liquids directly into the cell shaft. Always use a cell for measurement. The meter only measures accurately if the cell is closed with the black light protection cap (WTW cells).



The outside of the cell always has to be clean, dry, and free of fingerprints and scratches. Clean the cell before starting to measure (see section 5.2.2). Only hold the cells by the top or by the black light protection cap.

Measuring

- 1 Press the **<M>** key (long pressure) repeatedly until the *Turbidity* measuring mode is selected.
- 2 Rinse a clean cell with the sample to be measured: Pour approximately 10 ml sample into the cell. Close the cell and rotate it several times before throwing the sample away.
- 3 Repeat the rinsing procedure twice more.
- 4 Fill the cell with the sample to be measured (approx. 15 ml). Close the cell with the black light protection cap.
- 5 Clean the cell (see section 5.2.2).
- 6 Insert the cell (see section 4.2).
- 7 Align the cell:
 - Marked cell
 - Align the marking on the cell cap with the marking at the cell shaft.
 - Press the **START/ENTER>** key and for a short time keep it depressed until the measured value is displayed.
 - Unmarked cell (see page 56)
 - Press and keep the **<START/ENTER>** key depressed.
 - Slowly rotate the cell once completely in small steps (by 360 °).
 After each step, wait briefly until the displayed measured value is stable.
 - Turn the cell back to the position with the lowest measured value.



To keep the drift as low as possible, the time for aligning the cell while the **START/ENTER>** key is pressed is limited to 30 seconds. After this time, the meter starts the measurement or calibration automatically.


8 Release the **<START/ENTER>** key.

Measurement starts. The measured value is displayed.

Turbidity	FNU
157.0	NTU
	01.02.05 15:12

9 Repeat the steps 2 to 8 for further samples.

Display with measuring range overflow If the measured value is outside the measuring range of the pHotoFlex $^{\mbox{\tiny R}}$ Turb, it is indicated on the display:



4.7.4 Calibration

When to calibrate?

- Regularly every 90 days
- With a temperature change

Calibration procedure and calibration standards For the menu-guided three-point calibration, you need the following three calibration standards in the specified order:

Standard no.	NTU/FNU
1	1000
2	10.0
3	0.02

Preparing the calibration Perform the following preparatory activities when you want to calibrate:

- 1 Keep the cells with the required calibration standards ready and mark them as necessary (see page 56).
- 2 Clean the cell (see section 5.2.2).
- 3 Insert the cell (see section 4.2).

CAUTION



Carrying out calibration

1 Press the **<M>** key (long pressure) repeatedly until the *Turbidity* measuring mode is selected.

Never open the cells with the calibration standards!

2 Press the **<CAL/ZERO>** key.

The menu-guided calibration starts. Follow the instructions on the display.

Г	_ Turbidity \ Calibration
i	Insert standard
	1000 FNU/NTU
i	Press and hold <start></start>
i	Align sample
L	

3 Insert the cell with the displayed calibration standard (here e.g. 1000 NTU/FNU) in the cell shaft (see section 4.2).

- 4 Align the cell:
 - Marked cell:
 - Align the marking on the cell cap with the marking at the cell shaft.
 - Press the **START/ENTER>** key and keep it depressed until the measured value is displayed.
 - Unmarked cell (see page 56)
 - Press and keep the **<START/ENTER>** key depressed.
 - Slowly rotate the cell once completely in small steps (by 360 °).
 - After each step, wait briefly until the displayed measured value is stable.
 - Turn the cell back to the position with the lowest measured value.
 - Turbidity \ Calibration
 Turb. = 1000 FNU/NTU
 Start calibration
 by releasing <START>
- 5 Release the **<START/ENTER>** key.

Measurement of the calibration standard begins.



Before measuring the third calibration standard of 0.02 NTU/FNU you can exit the calibration with **<ESC>** at any time. The new calibration data are discarded. The old calibration data are used.

6 Repeat the steps 4 - 6 with the calibration standards, 10.0 NTU/FNU and 0.02 NTU/FNU.

After measuring the 0.02 NTU/FNU calibration standard, the calibration result (i *Calibration successful!* or i *Calibration error!*) is displayed and stored.

The calibration is complete.

7 Confirm the calibration result with **START/ENTER>**. The display shows instructions for the first measurement. Turbidity i Insert sample i Press and hold <START> i Align sample



If i *Calibration error!* is displayed as the calibration result, the display indicates that a new calibration is required before a measurement is taken. If a valid calibration is not possible, the meter also offers to continue measuring with the last valid calibration data.

4.8 Memory

The meter has 2000 storage locations for measurement datasets.

You can transmit measured values (datasets) to the data memory with the **<STO>** key.

Each data storing process transmits the current dataset to the interface at the same time.

The number of memory locations that are still free is displayed in the *Store* menu. The number of memory locations that are occupied is displayed in the *System / Measured value memory* menu.

Measurement dataset A complete dataset consists of:

- Date/time
- ID number (ID)
- and the following measurement data, depending on the selected measuring mode

Measuring mode	Measured data
Photometry: • Program number	
	 Measured value
	Citation form
	 Use of a blank value (BV)
	 Dilution (x +1)
Turbidity:	Measured value

pH & ORP:

- Measured value (pH/mV)
- Temperature value (°C/°F)
- AutoRead info (*AR*)

AR appears with the measured value if the AutoRead criterion was met while storing (stable measured value). Otherwise, the *AR* display is missing.

4.8.1 Storing measurement datasets

Proceed as follows to transmit to the data memory and simultaneously output to the interface a measurement dataset:

1 Press the **<STO>** key. The *Store* display appears.

Store (996 free)	
i 02.02.2005 11:24:16	
0.00 mg/l PO4-P BV	
PROG 1	
ID:	1
Store (ID: 1)	

- 2 Using <▲ > <▼ >, <START/ENTER> and the number keys, change and confirm the ID number (*ID*) as necessary (0 ... 999).
- 3 Using **START/ENTER** or **STO**, confirm *Store*. The dataset is stored. The meter switches to the measured value display.



A measurement dataset is quickly stored by twice pressing **<STO>**. It is stored with the ID last set.

If the memory is full

You can erase the entire memory (see section 4.8.5), or overwrite the oldest dataset with the next storing procedure. A security prompt appears before a dataset is overwritten.

4.8.2 Filtering measurement datasets

The functions to display and download stored measurement datasets (see section 4.4.1) refer to all stored measurement datasets that correspond to the specified filter criteria.

The settings are in the menu, Configuration / System / Measured value memory / Data filter.

Move to the *Configuration* menu with the **<MENU>** key.

Data filter	Menu item	Setting/function	Explanation
	Filter		Filter criteria:
		No filter	Data filter switched off
		ID	Selection according to ID num- ber
		PROG	Selection according to program
		Datum	Selection according to period
		ID + PROG	Selection according to program and ID number
		ID + Date	Selection according to period and ID number
		PROG + Date	Selection according to program and date
		ID + PROG + Date	Selection according to ID, pro- gram and date
	ID		Entry of filter criteria
	PROG	1	These menu items are made vis- ible by selecting the filter criteria
	Datum]	in the <i>Filter</i> menu.

4.8.3 Displaying measurement datasets

You can read out stored datasets to the display. Only those datasets are displayed that correspond to the selected filter criteria (see section 4.8.2).

Start reading out the data to the display in the menu, *Configuration / System / Measured value memory / Display*.

Representation of a dataset

02.02. ID: 1	.2005 11:24:16	6
	(pH) 24.8 °C	AR
i Sc	roll with A	
i Sc	eroll with 🔺 🔻	

Further datasets that correspond to the filter criteria are displayed with the $< > < \forall > keys$.

Quitting the dis-
playTo quit the display of stored measurement datasets, you have the following
options:

- Switch directly to the measured value display with <M> (short pressure).
- Leave the display and switch to the superordinate menu with <ESC> or <START/ENTER>.

4.8.4 Output measurement datasets to the RS232 interface

You can output stored datasets to the RS232 interface (see section 4.9). Only those datasets are downloaded that correspond to the selected filter criteria (see section 4.8.2).

The datasets are downloaded in the specified output format (see section 4.9.5).

The output of the data to the interface is started in the menu, *Configuration / System / Measured value memory / RS232 download.*

4.8.5 Erasing stored measurement datasets

You can erase the stored measurement datasets altogether if you no longer need them.

Erasing all measurement datasets is done in the menu, *Configuration / System / Measured value memory / Delete*.



Erasing individual datasets is not possible. If all memory locations are occupied, however, it is possible to overwrite the oldest dataset at a time. A security prompt appears before a dataset is overwritten.

4.9 Transmitting data

To transfer data from the pHotoFlex[®] Turb to a PC or printer, first establish a connection to a PC or printer (see section 4.9.1).

With the PC software LS Data you can, without further configuration, transmit or save measurement and calibration data for GLP-compliant data management to LS Data or transmit them to Excel and thus to LIMS (see section 4.9.2).

With the MultiLab[®] Importer (an add-in for Microsoft Excel) you can transmit data from the meter directly to an open Excel sheet (see section 4.9.3).

The connection to a printer or terminal program has to be configured so data can be safely transmitted (see section 4.9.5).

4.9.1 Establishing the connection to a PC

You have the following possibilities of transmitting data from the pHotoFlex $^{\ensuremath{\mathbb{R}}}$ Turb to a PC

- via the RS232 interface of the pHotoFlex[®] Turb or
- via the RS232 interface of the LabStation LS Flex/430 (accessories, see chapter 8)



The RS232 interface is not galvanically isolated.

When connecting an earthed PC/printer, measurements cannot be performed in earthed media as incorrect values would result.

- **Prerequisites** Microsoft Windows PC with one of the following operating systems:
 - Windows 7
 - Windows 8
 - Windows 10.
 - Free interface of the PC
 - Serial COM interface or
 - USB interface:
 - and USB adapter (accessory)
 - Connection to the PC
 - Connecting cable AK 540/B (accessory) or
 - LabStation LS Flex/430 (accessory, see chapter 8)

Establishing a connection

 Connect the pHotoFlex[®] Turb to the PC via the RS232 or via the LabStation LS Flex/430 (see operating manual LS Flex/430).

The connection to the PC is established. The data can be transferred to the PC:

- via the PC software LS Data (see section 4.9.2)
- via the MultiLab[®] Importer (see section 4.9.3)
- via a terminal program (see section 4.9.6).

4.9.2 Data transmission with the PC software LS Data

With the PC software LS Data you can transmit and save to the LS Data any measurement- and calibration data for GLP compliant data management (menu item *File / Save As... / **. csv (CSV format)) or transmit and save to Excel (menu item *Data exchange / Export (.xls)*) and thus transfer to LIMS.



The PC software LS Data is available as an accessory (LabStation LS Flex/430 with PC software LS Data, see chapter 8).

- 1 Establish the connection to a PC (see operating manual of the PC software LS Data and section 4.9.1).
- 2 Transmit data (see operating manual of the PC software LS Data).

4.9.3 Data transmission with the Excel add-in MultiLab[®] Importer



Set the CSV output format for datasets at the pHotoFlex[®] Turb. It is selected in the menu, *Configuration / System / Interface / Output format* (see section 4.9.4 ESTABLISHING THE CONNECTION TO A PRINTER).

- 1 Establish the connection to a PC (see section 4.9.1).
- 2 Establish a data connection (see operating manual MultiLab[®] Importer).
- 3 Transmitting data (see section 4.9.6).

4.9.4 Establishing the connection to a printer

Via the RS 232 interface, you can transmit data to an external printer.




The RS232 interface is not galvanically isolated. When connecting an earthed PC/printer, measurements cannot be performed in earthed media as incorrect values would result.

Suitable printers

- P3002 (see section 8 ACCESSORIES AND OPTIONS)
- P3001 (no longer available as accessory)

Socket assignment (RS232)



1 Connect the RS232 interface to the external printer with the AK540/ S cable.



The pHotoFlex $^{\ensuremath{\mathbb{R}}}$ Turb is pre-configured for the connection of the printer.

2 For error-free data transmission:

The RS232 interface of the pHotoFlex[®] Turb and the printer have to be set to the same transmission speed (*Baud rate*).

- The baud rate of the pHotoFlex[®] Turb is selected in the menu *Configuration / System / Interface / Baud rate.*
- The setting of the baud rate of the printer and the default setting are in the documentation of your printer.
- Selecting the output format of datasets (pHotoFlex[®] Turb)
 It is selected in the menu, *Configuration / System / Interface / Output format.*

Examples of the output formats (see section 4.9.6)

4 Transmitting data (see section 4.9.6). Examples of transmitted data (see section 4.9.7)

4.9.5 Configuration for the data transmission to a terminal program

Via the RS232 interface you can also transmit data to a PC with the aid of a so-called terminal program.



When using the terminal program "HyperTerminal", you can load the transfer data automatically with the *.ht file stored on the CD.

- 1 Establish the connection to a PC (see section 4.9.1).
- 2 Determine the output format of datasets at the pHotoFlex[®] Turb (see section 4.9.4 ESTABLISHING THE CONNECTION TO A PRINTER It is selected in the menu, *Configuration / System / Interface / Output format.*

Examples of the output formats (see section 4.9.6)

3 Configure the RS232 interface of the pHotoFlex[®] Turb and the terminal program.

The transmission data specified in the pHotoFlex[®] Turb and terminal program have to match.

- RS232 interface (see section 4.4.3).
- Terminal (see operating manual of your terminal).

Transmission data:

Baud rate	can be selected from: 1200, 2400, 4800, 9600, 19200
Handshake	none
Parity	none
Data bits	8
Stop bits	1

4 Transmit data (see section 4.9.6). Examples of transmitted data (see section 4.9.7)

4.9.6 Transmitting data to a printer or terminal program

With a printer connected or a connection to a terminal program existing, you can transmit data in the following ways:

Data	Operation / description	
Individual data (e.g. measured val- ue, calibration pro- tocol, AQS protocol)	 Display the data and press <prt>. The data being shown on the display are transmitted to the interface.</prt> Simultaneously with every manual storage process. 	
Stored measured values	 Display the saved data and press <prt>.</prt> All datasets according to the filter criteria (section 4.4) via the <i>Ausgabe RS232/USB</i> function (see section 4.8.2.). 	



With the **<PRT>** key you output data that is being shown on the display to the interface (displayed measured values, stored measurement datsets, calibration record).

4.9.7 Examples of data transmitted (printer, terminal program)

The data are output according to the selected output format.


The ASCII output format delivers formatted datasets.

pHotoFlex *Ser. no.* 12345678 31.10.04 09:56:20 ID: 1 10.01 (pH) AR 25 °C pHotoFlex *Ser. no.* 12345678 31.10.04 15:48:08 ID 1 / PROG 2 1.1 mg/l Pb [BV][9 + 1] etc...

Example; output format ASCII

Example, output format CSV

The CSV output format delivers datasets separated by ";". The data are output in the following order:



- 1 Current number of the storage location (or "0" during output from measured value display)
- 2 Date of storing
- 3 Time of storing
- 4 Selected ID
- 5 Program number (only for the measured parameter, *Concentra-tion*)
- 6 Citation form (only for the measured parameter, Concentration)
- 7 AR: Measuring mode *pH* & *ORP*: AutoRead BV: Measured parameter *Concentration*: Blank value
- 8 Dilution (only for the measured parameter, Concentration)
- 9 Main measured value or Upper/lower measuring range limit (only with measured value status, OFL/UFL)
- 10Unit of the main measured value or designation of dimensionless measured values, e.g. <pH>
- 11Measured value status of the main measured value
 - * VALID: Measured value valid
 - * INVALID: Measured value invalid
 - * UFL: Measured value below the lower measuring range limit
 - * OFL: Measured value above the upper measuring range limit
- 12Secondary measured value

with measured parameter, *pH* & *ORP*: Temperature with measured parameter, *Absorbance / % Transmission*: Wavelength of measurement

- 13Unit of the secondary measured value for the measured parameter, *pH* & *ORP*: °C / °F with measured parameter, *Absorbance* / % *Transmission*: nm
- 14Measured value status of the secondary measured value (see 11)



If the connected external printer does not print, please check whether the same baud rate is set at the pHotoFlex[®] Turb and printer.

4.10 Reset

You can reset (initialize) all system and measurement settings.



For turbidity measurements, there are no settings that can be reset.

4.10.1 Resetting the system settings

With the System / Reset function, all resettable settings are reset.

- Settings for *pH* & *ORP* (see section 4.10.3)
- Settings for *Photometry* (see section 4.10.2)
- System settings

System setting	Default settings
Baud rate	4800 Baud
Output format	ASCII
Illumination	Auto off
Contrast	50 %
Brightness	50 %
Switchoff time	30 min
Веер	On
Measuring mode	Photometry

4.10.2 Resetting the photometry settings

With the *Photometry / Reset* function, all settings are reset.

Setting	Default settings
PROG	0
Cell size	16 mm
Meas. param.	Concentration
Wavelength	436 nm
Blank values	all erased

4.10.3 Resetting the settings for pH measurements



The calibration data are reset to the default settings together with the measuring parameters. Recalibrate after performing a reset.

The following settings for pH measurements are reset to the default settings with the *Reset* function:

Setting	Default settings
Calibr. type	TEC
Calibr. interval	7 d
Meas. param.	pH & ORP
Asymmetry (Asy)	0 mV
Slope (Slp.)	-59.16 mV/pH
Temperature manual	25 °C
Temperature	°C

4.11 Meter information

The following meter information is listed in the Configuration / Info menu:

- Model designation
- Software version
- Version number(s) of the stored program data
- Series number of the meter

	_Info
i	<i>Model</i> : pHotoFlex
i	Software: V 0.35
i	Prog.: V 0.07
i	Ser. no.: 04280003

4.12 Software update

With a software update you obtain the current software with all new programs and method data (see section 11).

A software update comprises

- new instrument software
- new programs (methods)
- revisions of existing methods

The current software version can be found on the Internet at <u>www.WTW.com</u>.

The proceeding for updating the software is given in the appendix (see section 11).

4.13 Administrating user-defined methods

User-defined programs can be

- entered
- read out
- erased.

To store user-defined programs (methods) in the meter, determine a calibration line for your method yourself and transmit the data of this calibration line to the pHotoFlex[®] Turb.

Administration of the method data can be carried out in the LSdata software (see LSdata operating manual) or with the aid of a terminal program (see section 4.13.1).

You need the following data in any case:

Data	Possible entries/examples
Program No:	900 999
Model:	Any name (max. 5 characters)
Cuvette [mm]:	16 or 28
Wave length [nm]:	436, 517, 557, 594, 610 or 690
<i>MRB</i> : (measuring range beginning)	e.g. 0.05
<i>MRE</i> : (measuring range end)	e.g. 8.00
E0: (Offset)	e.g. 0.0
Slope: (slope)	e.g. 1.0
Resolution: (resolution)	0.0001, 0.001, 0.01, 0.1, 1, 2, 5, 10 or 100
Formula: (citation form)	e.g. PO4-P (max. 9 characters)

Data	Possible entries/examples
Unit (unit)	e.g. mg/l (max. 7 characters)
Blank required: (No/Yes)	0 or 1

4.13.1 Administrating user-defined programs with a terminal program

Generally, a terminal program serves to establish a connection to a device on a data interface and to communicate with the device via a console on the display.

Thus, it is also possible to send command lines.

Terminal programs are available for different operating systems by different manufacturers. Windows (version 95 to XP) contains the "HyperTerminal" terminal program. It is in the program menu under *Accessories*.

For more detailed information please refer to the user information of the terminal program.



On the CD-ROM there is a configuration file for the HyperTerminal program. By double clicking the configuration file (*.ht) you open the HyperTerminal program with the presettings required for data exchange with the meter.

The pHotoFlex[®] Turb can administrate the database of user-defined programs via command lines.

- 1 With the aid of the AK 540/B interface cable, connect the pHotoFlex[®] Turb to the serial interface (COM port) of the PC (see section 8.1.1).
- 2 Make sure the pHotoFlex[®] Turb is switched on.
- 3 Start the terminal program on the PC.
- 4 Configure the connection settings for the COM interface as necessary.

Storing user- Enter a command line according to the following scheme in the terminal pro**defined programs** gram:

U.500#14, *Program No, Model, Cell [mm], Wave length [nm], MRB, MRE, E0, Slope, Resolution, Citation form, Unit, Blank required, 0, 0*

Example:

U.500#14,900,Test,16,436,0.0,2.0,0.0,1.0,0.01,test,mg/ 1,0,0,0 The individual data sections of the command line are separated by commas. The dot "." has to be used as a decimal separator within a data section.

- 5 Enter the command line.
- 6 Finish the command line with Enter.

The data is transmitted to the pHotoFlex[®] Turb.



If there is already a program stored under the selected number, the programming is canceled. If you wish to store the program under the selected number, you have to erase the program stored under the number first.

After a successful transmission, the terminal program writes "!>". After a failed transmission, the terminal program writes "?>".

Erasing user- To erase user-defined programs, enter a command line according to the following scheme in the terminal program:

	Erase all user-defined programs	Erase one user-defined program
Command line	U.520	U.521#1,Program No
Example	U.520	U.521#1,900

- 7 Enter the command line.
- 8 Finish the command line with Enter.
 The data is transmitted to the pHotoFlex[®] Turb.
 The requested data is displayed on the terminal as the result.

After a successful transmission, the requested data is displayed on the terminal.

After a failed transmission, the terminal program writes "?>".

Reading out user- To read out user-defined programs, enter a command line according to the following scheme in the terminal program:

	Read out all user-de- fined programs	Read out one user-de- fined program
Command line	U.510	U.511#1,Program No
Example	U.510	U.511#1,900

9 Enter the command line.

Finish the command line with Enter.
 The data is transmitted to the pHotoFlex[®] Turb.
 The requested data is displayed on the terminal as the result.

After a successful transmission, the terminal program writes "!>". After a failed transmission, the terminal program writes "?>".

5 Maintenance, cleaning, disposal


5.1 Maintenance

The meter is almost maintenance-free. The only maintenance task is replacing the batteries or battery pack.

5.1.1 Inserting/exchanging the batteries

NOTE

Make sure that the poles of the batteries are positioned correctly. The \pm signs on the batteries must correspond to the \pm signs in the battery compartment.



- 1 Open the battery compartment:
 - Unscrew the two screws (1) on the underside of the meter
 - Remove the lid of the battery compartment (2).
- 2 If necessary, take four old batteries out of the battery compartment.
- 3 Insert four batteries (3) in the battery compartment.
- 4 Close the battery compartment and fix it with the screws.



Dispose of used batteries according to the local regulations of your country.

End users within the European Union are obligated to return used batteries (even ecologically compatible ones) to a collection point set up for recycling purposes.


Batteries are marked with the crossed-out waste container symbol. Therefore, they may not be disposed with the domestic waste.

5.1.2 Retrofitting the battery pack

NOTE

Use original WTW battery packs only.

Together with the power pack the battery pack is available as an accessory (see section 8.1).



- 1 Open the battery compartment:
 - Unscrew the two screws (1) on the underside of the meter,
 - Remove the lid of the battery compartment (2).

- 2 If necessary, take four old batteries out of the battery compartment.
- 3 Connect the cable of the battery pack with the socket (3) on the bottom of the battery compartment and insert the battery pack in the battery compartment.
- 4 Close the battery compartment and fix it with the screws.



Dispose of used batteries according to the local regulations of your country.

End users within the European Union are obligated to return used batteries (even ecologically compatible ones) to a collection point set up for recycling purposes.

Batteries are marked with the crossed-out waste container symbol. Therefore, they may not be disposed with the domestic waste.

5.2 Cleaning

Occasionally wipe the outside of the measuring instrument with a damp, lintfree cloth. Disinfect the housing with isopropanol as required.

NOTE

The housing parts are made of plastic (polyurethane, ABS and PMMA) and are only conditionally resistant against organic solvents. Thus, avoid contact with acetone and similar detergents that contain solvents. Remove any splashes immediately.

5.2.1 Cleaning the cell shaft

If liquid is in the cell shaft (e.g. due to a spilled cell), clean the cell shaft as follows:



CAUTION

Cells may contain toxic or corrosive substances. If the contents are released, observe the hazard information on the cell. If necessary, take corresponding protective measures (protective goggles, protective gloves etc.).

- 1 Switch the pHotoFlex[®] Turb off and pull out the power plug.
- 2 Rinse the cell shaft with distilled water.

5.2.2 Cleaning the cells

Cells have to be clean, dry, and free of fingerprints. Therefore, clean them regularly:

- 1 Clean the cells inside and out with hydrochloric acid or laboratory soap.
- 2 Rinse several times with distilled water.
- 3 Let them dry in the air.
- 4 Only hold the cells by the top or by the light protection cap so that the optical path is not impaired.
- 5 Before measuring, clean the cell with the enclosed cleaning cloth.

5.3 Packing

This meter is sent out in a protective transport packing.



We recommend: Keep the packing material. The original packing protects the meter against damage during transport.

5.4 Disposal

- **Batteries** Dispose of used batteries according to the local regulations of your country (see section 5.1.1).
 - Meter At the end of its operational lifetime, the meter must be returned to the disposal or return system statutory in your country. If you have any questions, please contact your supplier.

6 What to do if...

6.1 General errors

Display, <i>LoBat</i>	Cause	Remedy
	 Batteries or battery pack almost empty 	 Insert new batteries Charge the battery pack(see section 3.2)

Meter does not	Cause	Remedy
react to keystroke	 Software error Operating condition undefined or EMC load unallowed 	 Processor reset: Press the <start enter=""></start> and <prt></prt> key simultaneously.

RS232 interface does not react	Cause	Remedy
does not react	 Software error Operating condition undefined or EMC load unallowed 	 Processor reset: Press the <start enter=""></start> and <prt></prt> keys simultaneously.

Error message, <i>Error</i>	Cause	Remedy
0, 8, 16, 16384	 Instrument error 	 Repeat measurement Meter defective,
		Send in the meter for repair, stating the error number

6.2 Photometry

Measuring range exceeded or	Cause	Remedy
undershot	 Program not suitable 	Select a program with suitable measuring rangeDilute the sample

Obviously incorrect measured values

Cause	Remedy
 Measurement disturbed by extraneous light 	 Close extraneous light flap
 Cell not correctly inserted 	 Insert the cell until it is positioned on the bottom of the cell shaft.
- Cell contaminated	- Clean the cell
- Cell shaft contaminated	 Clean the cell shaft
 Dilution set incorrectly 	 Set the dilution
- Selected program not suitable	 Select a different program
 Incorrect zero measurement 	 Carry out a zero measurement
 Incorrect blank value 	- Measure the blank value once again

6.3 pH value / ORP voltage

Measuring range exceeded or undershot

Cause	Remedy	
Electrode:		
 Air bubble in front of the junction 	 Remove the air bubble 	
 Air in the junction 	 Extract air or moisten junction 	
- Gel electrolyte dried out	 Replace the electrode 	
Test sample:		
 The pH value lies outside the measuring range 	 Not possible 	

Measured value	Cause	Remedy
display 	Electrode:	·
(calibration error)	 Junction contaminated 	- Clean the junction
	 Membrane contaminated 	- Clean the membrane
	 Moisture in the plug 	- Dry plug
	 Too little electrolyte 	- Refill the electrolyte
	 Electrode obsolete 	- Replace the electrode
	 Electrode broken 	 Replace the electrode
	 Socket damp 	 Dry the socket
	Calibration procedure:	
	 Solution temperature incorrect (without temperature sensor) 	 Set the correct temperature
	 Incorrect buffer solutions 	 Select the suitable buffer solutions for the calibration procedure
	 Buffer solutions too old 	 Use only once. Note the shelf life

No stable mea-	Cause	Remedy			
sured value	pH electrode:	pH electrode:			
	 Junction contaminated 	- Clean the junction			
	 Membrane contaminated 	- Clean the membrane			
	Test sample:	·			
	 pH value not stable 	 Measure with air excluded if necessary 			
	 Temperature not stable 	- Temper if necessary			
	Electrode + test sample:				
	 Conductivity too low (e.g. in ultrapure water) 	 Use suitable electrode 			
	 Temperature too high 	- Use suitable electrode			
	- Organic liquids	 Use suitable electrode 			

Obviously incor-Remedy Cause rect measured valpH electrode: ues not connected - Connect electrode - Cable broken - Exchange the cable or electrode pH electrode unsuitable - Use suitable electrode - Temperature difference - Adjust temperature of buffer or between buffer and test sample solutions sample too great - Measurement procedure not - Follow special procedure suitable

Sensor symbol Cause flashes	Remedy	
lidslies	- Calibration interval expired	 Recalibrate the measuring system

6.4 Turbidity

Error message Measured values obviously incorrect

Cause	Remedy
 Cell not correctly inserted 	 Lock the cell into place
- Cell contaminated	- Clean the cell
 Calibration too old 	 Carry out calibration

Measured value display < 0.01 FNU

Cause	Remedy
 Measured value outside the measuring range 	 Not possible

7 Technical data

7.1 General data

Dimensions	Approx. 236 x 86 x 117 mm		
Weight	Approx. 0.6 kg (without batteries)		
Mechanical structure	Type of protection	IP 67	
Electrical safety	Protective class	111	
Test certificates	CE, FCC		
Ambient	Storage	- 25 °C + 65 °C	
conditions	Operation	0 °C + 50 °C	
	Climatic class	2	
Allowable relative hu- midity	Yearly mean: 30 days /year: Other days:	75 % 95 % 85 %	
Power	Batteries	4 x 1.5 V, type AA	
supply	Operating time with battery operation	approx. 5000 measurements	
	Battery pack (optional)	5 x 1.2 V nickel metal hydride (NiMH), type AA	
	Power pack/ charging device (optional)	FRIWO FW7555M/09, 15.1432.500-00 Friwo Part. No. 1883259	
		RiHuiDa RHD20W090150	
		Input: 100 240 V ~ / 50 60 Hz / 400 mA Output: 9 V = / 1.5 A Connection max. overvoltage category II Primary plugs contained in the scope of de- livery: Euro, US, UK and Australian.	

Serial	Connection of the cable AK 540/B or AK 540/S		
interface	Baud rate	Adjustable: 1200, 2400, 4800, 9600, 19200 baud	
	Туре	RS232	
	Data bits	8	
	Stop bits	2	
	Parity	None	
	Handshake	RTS/CTS	
	Cable length	Max. 15 m	
Guidelines	EMC	EC guideline 89/336/EEC	
and norms used		EN 61326-1/A3:2003	
		FCC Class A	
	Meter safety	EEC guideline 73/23/EEC	
		EN 61010-1 :2001	
	Climatic class	VDI/VDE 3540	
	IP protection class	EN 60529:1991	

7.2 Photometry

Optical measuring prin- ciple	LED photometer with filter		
Interference filter	436 nm, 517 nm, 557	nm, 594 nm, 610 nm, 690 nm	
	Accuracy:	± 2 nm	
Photometric reproducibility	0.005 or better		
Photometric resolution	0.001		
Warm-up time	None		
Measuring time	Approx. 2s		
Measured parameters	Concentration (method dependent, selectable display type), absor- bance, transmission		
Measuring range	Absorbance: -2.000 +2.000		
	Transmission:	1 150 %	
User-defined programs	100		
Resolution Transmission	1.00 9.99	0.01 %	
	10.0 150 0.1 %		

7.3	pH value /	ORP voltage
-----	------------	-------------

Variable	Measuring range	Resolution
pН	- 2.00 + 16.00	0.01
U [mV]	- 1000 + 1000	1
T [°C]	- 5.0 + 100.0	0.1
T [°F]	- 23.0 + 212.0	0.1
Variable	Range	Increment
T _{manual} [°C]	- 20 + 100	1
	pH U [mV] T [°C] T [°F] Variable	pH - 2.00 + 16.00 U [mV] - 1000 + 1000 T [°C] - 5.0 + 100.0 T [°F] - 23.0 + 212.0 Variable Range

Accuracy (± 1 digit)	Variable	Accuracy	Temperature of the test sample
	pH *	± 0.01	+ 15 °C + 35 °C
	U [mV]	± 1	+ 15 °C + 35 °C
	T [°C]	± 0.3	0 °C + 55 °C
	T [°F]	± 0.54	0 °C + 55 °C

 * when measuring in a range of \pm 2 pH around a calibration point

7.4 Turbidity

Measuring principle	Nephelometric measurement according to DIN EN ISO 7027		
Light source	Infrared LED		
Measuring range	0.01 1100 NTU/FNU		
Resolution	In the range 0.01 9.99	max 0.01 NTU/FNU	
	In the range 10.0 99.9	max 0.1 NTU/FNU	
	In the range 100 1100	max 1 NTU/FNU	
Accuracy	In the range 0 1000 NTU/FNU	± 2% of the measured value or ± 0.01 NTU/FNU	
Measuring time	4 seconds		
Calibration	Automatic 3-point calibration		

8 Accessories and options

8.1 Accessories

Description	Model	Order no.
LabStation with PC software LSdata, battery pack and universal power pack	LS Flex/430	251 301
Batteries for pHotoFlex	RB Flex/430	251 300
3 replacement cells, 28 x 60 mm	LKS28-Set	251 302
Calibration set for Turb 430 IR/photoFlex Turb	Kal.Kit Turb 430 IR	600 560
Thermoprinter [*]	P3001	250 045
Matrix printer*	LQ 300+	250 046
16 mm cells	RK 14/25	250 621

A connection cable is required to connect the printer (see section 8.1.1)

8.1.1 Connecting cable

*

PC You can connect a PC to the pHotoFlex[®] Turb in one of the following ways:

Description	Model	Order no.
 Connection PC - pHotoFlex[®] Turb 		
– Cable	AK 540/B	902 842
+ USB adapter (for USB connection on PC)	Ada USB	902 881
Connection PC - LabStation		
 Zero modem cable 	included in the scope of delivery of the LabStation	
+ USB adapter (for USB connection on PC)	Ada USB	902 881

Thermoprinter	You can connect the P3001 to the pHotoFlex $^{\ensuremath{\mathbb{R}}}$ Turb in the following ways:		
	Description	Model	Order no.
	 Connection P3001 - pHotoFlex[®] Turb 	1	1
	- Cable	AK 540/S	902 843
	 Connection P3001 - LabStation 		
	– Cable	AK 3000	250 745
	in conjunction with an adapter (socket - socket) [GenderChanger]	Specialist sh	ops
	or:		
	 Cable, 2 x 9-pin (socket - plug) 	Specialist sh	ops
	Description	Model	Order no.
	 Connection LQ300 - pHotoFlex[®] Turb 		
	– Cable	AK 540/B	902 842
	with adapter 9-pin (plug) - 25-pin (plug)	Specialist sh	ops
	 Connection LQ300 - LabStation 		
	- Cable	AK/LQ300	250 746
	in conjunction with an adapter (socket - socket) [GenderChanger]	Specialist sh	ons
	or:		003
	or:		

8.2 Optional extensions of the pHotoFlex[®] Turb

The following optional extensions are available in specialist shops:

Device/cable	Model
Bar code reader [*]	 Handscanner Datalogic DLC6065-M1 Handscanner Datalogic Touch65
Connection cable Bar code reader - LabStation	Datalogic CAB-350

 In addition to the bar code reader, a suitable connection cable is required to operate the bar code reader

9 Lists

This chapter provides additional information and orientation aids.

Abbreviations	The list of abbreviations explains the indicators and the abbreviations that appear on the display and in the manual.
Specialist terms	The glossary briefly explains the meaning of the specialist terms. However, terms that should already be familiar to the target group are not described here.

Abbreviations

°C	Temperature unit, degrees Celsius
°F	Temperature unit, degrees Fahrenheit
Asy	Asymmetry
Cal	Calibration
d	Day
h	Hour
j	Year
K	Temperature unit, Kelvin
LoBat	Batteries almost empty (Low battery)
m	Month
mV	Voltage unit
mV/pH	Unit of the electrode slope (internat. mV)
NIST/DIN	Automatic calibration for pH measurements with buffer solutions, produced according to NIST or DIN 19266
рН	pH value
S	Second
S	Slope (internat. k)
SELV	Safety Extra Low Voltage
Slp.	Slope determined with calibration
TEC	Automatic calibration for für pH measurements with WTW Technical buffer solutions according to DIN 19267
U	Voltage

Glossary

Adjusting	To manipulate a measuring system so that the relevant value (e.g. the displayed value) differs as little as possible from the correct value or a value that is regarded as correct, or that the difference remains within the tolerance.
Analysis specification	The exact proceeding to carry out the detection procedure is described in the analysis instructions.
Asymmetry	Designation of the offset potential of a pH electrode. It is the measur- able potential of a symmetrical electrode, the membrane of which is immersed in a solution with the pH of the nominal electrode zero point (WTW electrode pH = 7).
AutoRange	Name of the automatic selection of the measuring range.
AutoRead	WTW name for a function to check the stability of the measured value.
Blank value (reagent blank value)	The evaluation of the photometric measurement always refers to the comparison value of a sample without the substance to be determined (reagent blank value). Thus the influence of the basic absorbance of the reagents on photometric measurement is compensated for.
Calibration	Comparing the value from a measuring system (e.g. the displayed value) to the correct value or a value that is regarded as correct. Often, this expression is also used when the measuring system is adjusted at the same time (see adjusting).
Cell	Vessel that takes a liquid sample for the photometric measurement. The cell material (mostly glass) must have certain optical features to be suitable for photometry.
Citation forms	Different forms of representing a measured concentration value that can be derived from each other. The method for determining phosphate provides, for example, a mea- sured value for phosphorous P. This measured value can also be quoted in other citation forms such as PO4, PO4-P or P2O5.
Detection procedure	The detection procedure designates the general principle of how a sample is brought into a form suitable for measurement. Different methods can be based on the same detection procedure.
Electrode zero point	The zero point of a pH combination electrode is the pH value at which the electromotive force of the pH combination electrode at a specified temperature is zero. Normally, this is at 25 °C.
Electromotive force of an electrode	The electromotive force U of the combination electrode is the measur- able electromotive force of an electrode in a solution. It equals the sum of all the galvanic voltages of the combination electrode. Its dependen- cy on the pH results in the electrode function, which is characterized by the parameters, slope and zero point.

Junction	The junction is a porous body in the housing wall of reference elec- trodes or electrolyte bridges. It arranges the electrical contact between two solutions and makes the electrolyte exchange more difficult. The expression, junction, is also used for ground or junction-less transi- tions.
LED	Light Emitting Diode LEDs are used as the light source in the pHotoFlex [®] Turb.
Measured parameter	The measured parameter is the physical dimension determined by measuring, e.g. pH, conductivity or D.O. concentration.
Measured value	The measured value is the special value of a measured parameter to be determined. It is given as a combination of the numerical value and unit (e. g. 3 m; 0.5 s; 5.2 A; 373.15 K).
Measuring system	The measuring system comprises all the devices used for measuring, e.g. measuring instrument and sensor. In addition, there is the cable and possibly an amplifier, terminal box and armature.
Method	A method comprises a chemical detection procedure and special method data (calibration line) that are required to evaluate the mea- surement results. How to carry out the method up to the photometric measuring is de- scribed in the analysis instructions. The pHotoFlex [®] Turb contains a database with methods (programs). Furthermore, user-defined methods can be entered in the database as well.
Molality	Molality is the quantity (in Mol) of a dissolved substance in 1000 g solvent.
MultiCal [®]	WTW name stating that a meter provides several pH calibration pro- cedures.
Offset potential	The measurable potential of a symmetrical electrode, the membrane of which is immersed in a solution with the pH of the nominal electrode zero point. The asymmetry is part of the offset potential .
ORP	The ORP is caused by oxidizing or reducing substances dissolved in water if these substances become effective on an electrode surface (e.g. a gold or platinum surface).
pH value	The pH value is a measure of the acidic or basic effect of an aqueous solution. It corresponds to the negative decadic logarithm of the molal hydrogen ions activity divided by the unit of the molality. The practical pH value is the value of a pH measurement.
Potentiometry	Name of a measuring technique. The signal (depending on the mea- sured parameter) of the electrode is the electrical potential. The elec- trical current remains constant.

Program	In the pHotoFlex [®] Turb, methods with the relevant method data are stored as programs. Programs are called up via the assigned program number.
Reset	Restoring the original condition of all settings of a measuring system.
Resolution	Smallest difference between two measured values that can be displayed by a meter.
Slope	The slope of a linear calibration function.
Standard solution	The standard solution is a solution where the measured value is known by definition. It is used to calibrate a measuring system.
Temperature function	Name of a mathematical function expressing the temperature behav- ior of a test sample, a sensor or part of a sensor.
Test sample	Designation of the test sample ready to be measured. Normally, a test sample is made by processing the original sample. The test sample and original sample are identical if the test sample was not processed.
Test set (test)	A test set contains all reagents that are required for the photometric determination of the sample according to the analysis instructions.
Zero adjustment	Adjusting a photometer with a water-filled cell. The zero adjustment applies to measuring all measured parameters (concentration, absorbance, transmission) of a photometer.

10 Index

Α

Absorbance / % Transmission, measuring Air	
Aligning and marking a cell	
Analysis specification	31
Analysis timer	43
Asymmetry of the pH electrode	49
Automatic switch-off function14	, 17
AutoRead	
ORP	48
рН	47

В

Blank value		
Blank value r	neasurement	36

C

Calibration	
рН	49
Turbidity measurement	
when?	59
Calibration evaluation	
рН	51
Calibration order	59
Calibration points	
рН	50
Calibration points and measuring ranges	59
Calibration standards	59
Cleaning	80
Concentration measurement	
Connecting sensors	9
Connectors	

D

Data filter	64
Data memory	29
Dataset	62
Date and time	24
Date/time	31
Default settings	
Measured parameter	73
System settings	72
Display9), 30
Display illumination9), 18
Drift control	
ORP	48

pН	
----	--

F

Filter	64
Firmware update	99

I

Initial commissioning	
Initialize	
Inserting a cell	
Interface	

Κ

Key functions	7
Keys	7

Μ

Measure diluted sample Measured value display	
Measurement data memory Storage locations Measurement dataset	
Measuring	
ORP	47
рН	47
Measuring menu	
pH/ORP	. 29, 48
Measuring range exceeded	
Measuring the turbidity	58
Menus (navigation)	
Messages	
Method	

Ν

Navigation	 21
Naviyalion	 <u> </u>

0

Operating modes		20
-----------------	--	----

Ρ

pH buffer sets	49
Photometric determination	31
Power pack	13
Program	31

Programs		13
----------	--	----

R

Rechargeable battery	
Charging time	13
Reset	72
RS232 socket assignment	68

S

11
13
54
49
62
17
33
28
31

Т

Temperature measurement pH4	16
Test set	
Three-point calibration	
рН5	55
Timer 4	14
Transmitting data6	6
Transmitting measured values	
Turbidity5	56
Two-point calibration	
pH5	54

U

User-defined programs .	
-------------------------	--

Ζ

Zero adjustment	
Zero adjustment	

11 Firmware update

General information With the aid of a PC, you can update the firmware of the pHotoFlex[®] Turb to the latest version.

You can find available firmware update files for your meter on the Internet.

The update program contains:

- the newest firmware (meter software)
- new or changed method data and programs.

Connecting the meter to the PC

The following is required for connection to a PC:

- a free serial interface (COM or USB port) on your PC
- cable or LabStation with cable for connection to PC
 - for direct connection of the meter to the PC: the AK 540/B interface cable (accessory) or
 - for connection with the LabStation: an operable LabStation with null modem cable (accessory, see section 8.1)
- for connection to a USB interface on the PC: a USB adapter (accessory).



Prior to starting the update please make sure that the batteries are fully loaded, or operate the pHotoFlex[®] Turb on the LabStation or with the power pack. Otherwise there is the risk of the pHotoFlex[®] Turb crashing during the update.

Program installa-	Install the firmware update program on your PC.
tion Program start	Start the program from the Windows start menu. Via the language menu you can change the adjusted language.
	Under Microsoft Windows 7, administrator rights are required.
Firmware update	Proceed as follows:
	1 Connect the pHotoFlex [®] Turb to an interface (COM port) of the PC .
	2 Make sure the pHotoFlex [®] Turb is switched on.
	3 To start the updating process click the OK button.
	4 Then follow the instructions of the program. The programming process takes approx. 5 minutes. A terminatory message is displayed after a successful programming process. The firmware update is now completed.

5 Disconnect the meter from the PC. The meter is ready for operation.

After switching the meter off and on you can check whether the meter has taken over the new software version on the start display.

12 Appendix: Turbidity values under 1 FNU/NTU

With turbidity values under 1 FNU/NTU, the measured value is strongly influenced by the cell and its alignment.

To increase measurement accuracy with turbidity values under 1 FNU/NTU, calibration in the 0.02 FNU/NTU standard and later measurement should take place in the same cell. For calibration with the 10.0 and 1000 FNU/NTU standards, follow the instructions on the display.

To measure turbidity values below 1 FU/NTU, proceed as follows:

Calibration	 Press the <cal zero=""> key.</cal> The menu-guided calibration starts.
	2 Perform calibration of the 1000 FNU/NTU and 10.0 FNU/ NTU standards according to the menu guidance in a clean, unscratched cell.
	3 Fill the cleaned cell with the standard 0.02 FNU/NTU and calibrate it.
	4 Mark the alignment of the cell.
	Calibrate
	 After the calibration interval has expired
	With a temperature change
Measuring	5 Fill the marked, cleaned cell with test sample, align it with the marking and measure.
	6 If necessary, fill the marked and cleaned cell with test sample again and carry out further measurements.

Xylem |ˈzīləm|

1) The tissue in plants that brings water upward from the roots;

2) a leading global water technology company.

We're a global team unified in a common purpose: creating advanced technology solutions to the world's water challenges. Developing new technologies that will improve the way water is used, conserved, and reused in the future is central to our work. Our products and services move, treat, analyze, monitor and return water to the environment, in public utility, industrial, residential and commercial building services settings. Xylem also provides a leading portfolio of smart metering, network technologies and advanced analytics solutions for water, electric and gas utilities. In more than 150 countries, we have strong, long-standing relationships with customers who know us for our powerful combination of leading product brands and applications expertise with a strong focus on developing comprehensive, sustainable solutions.

For more information on how Xylem can help you, go to www.xylem.com.



Service and Returns: Xylem Analytics Germany Sales GmbH & Co. KG WTW Am Achalaich 11 82362 Weilheim Germany

Tel.: +49 881 183-325 Fax: +49 881 183-414 E-Mail wtw.rma@xylem.com Internet: www.xylemanalytics.com



Xylem Analytics Germany GmbH Am Achalaich 11 82362 Weilheim Germany