



Alyza IQ: The Simple choice for NH₄ Analyzers





a xylem brand

How much reagent does your analyzer use?

Less Reagents

Minimized reagent consumption and waste

Simple Service

Minimum maintenance with automatic cleaning and calibration

Better Data

Reliable results from low to high measuring levels



The Alyza IQ NH_4 is fully integrated into the IQ SENSOR NET as a sensor. The new analyzer can be operated in the system 2020 and the System 282/284.

Learn more about IQ SENSOR NET on our website: <u>www.IQ-Sensor.Net</u>



Learn more about Alyza IQ NH₄ on our website: www.WTW.com/Alyza-IQ



Simple Service

Built with Service in mind, all service items can be quickly and easily exchanged without calling a service technician or service contracts.

Long Life Reagents

Easy and safe reagent replacement with no-drip reagent pouches.

Clear Information

Clear measurement menu - even for 2 channel versions and monitoring of reagent life time.

Ammonium measurement

Method

Indophenol method according to DIN 38 406

As the name suggests, the Indophenol method results in a blue coloration of the sample. The color is generated by the reaction of ammonium ions from the sample with hypochlorite ions and carbolic acid or a carbolic acid derivative under alkaline conditions (pH approx. 12.6). For acceleration of the reaction, a catalyst is used. The reaction can be sped up further by increasing the temperature of the reaction solution. The colored sample then is analyzed photometrically in the red spectral range. The higher the ammonium concentration, the more intense the blue coloration.

Fields of application

Wastewater treatment plant effluent monitoring

- High measuring accuracies even at low concentrations
- Easy handling due to optimized user interface
- Increased employee protection by safe exchange of reagents



River monitoring


- Long lifetime of reagents due to minimum consumption
- Minimal maintenance effort reduces work and travel times
- Full remote access via IQ WEB CONNECT, at any time



Configuration examples Alyza IQ NH₄ in IQ SENSOR NET

Example 2 - System 282/284

Example 1 - System 2020



Neither example 1 nor example 2 needs a power supply module MIQ/PS, as the Alyza IQ provides 10W to the systems.

Technical data

Model	Alyza IQ NH ₄			
Measurement method	Berthelot method (Indophenol method)		0.02 5.00 mg/l NH ₄ -N 0.00 5.00 mg/l NH ₄ -N 0.01 mg/l NH ₄ -N ±2 % ±0.02 mg/l	
Measurement range	Two measuring ranges	Displayed: Resolution:		
Sample streams/channels	1- and 2-channel versions available			
Cleaning	Automatic cleaning with cleaning solutions	MR2:	0.00 20.00 mg/l NH ₄ -N 0.01 mg/l NH ₄ -N	
Calibration	Automatic 1- and 2-point calibrations	Displayed: Resolution:		TD
Operational temperature	-4 104 °F (-20 +40) °C	Accuracy:		D2.24

Order information

Model	Description	Order no.
Alyza IQ NH ₄ -111	NH ₄ analyzer, 1-channel, with 2 measuring ranges, Indophenol method, connectable to IQ SENSOR NET Systems 2020 and 282/284, provides 10 W to the IQ SENSOR NET; including 2m SNCIQ cable; reagnet sets need to be ordered separately	825011
Alyza IQ NH ₄ -112	NH ₄ analyzer, 2-channel, with 2 measuring ranges, Indophenol method, connectable to IQ SENSOR NET Systems 2020 and 282/284, provides 10 W to the IQ SENSOR NET; including 2m SNCIQ cable; reagnet sets need to be ordered separately	825012
Reagent sets		
R-Set NH4/1-1	Reagents for Alyza IQ NH_4 , when using MR1	827540
R-Set NH4/1-2	Reagents for Alyza IQ NH ₄ , when using MR2	827541
SC-Set NH4/1-1_0/1	Calibration standards and cleaning solution for Alyza IQ NH $_4$, when using MR1; Calibration standards with 0 mg/l and 1 mg/l	827545
SC-Set NH4/1-1_0/4	Calibration standards and cleaning solution for Alyza IQ NH $_4$, when using MR1; Calibration standards with 0 mg/l and 4 mg/l	827546
SC-Set NH4/1-2_0/16	Calibration standards and cleaning solution for Alyza IQ NH ₄ , when using MR2; Calibration standards with 0 mg/l and 16 mg/l	827547



Xylem Analytics Germany Sales GmbH & Co. KG, WTW · Am Achalaich 11 · D-82362 Weilheim · Germany Phone: +49 881 183-0 · Fax: +49 881 183-420 · E-Mail: Info.WTW@xylem.com · www.xylemanalytics.com



All names are registered tradenames or trademarks of Xylem Inc. or one of its subsidiaries. Technical changes reserved. © 2019 Xylem Analytics Germany Sales GmbH & Co. KG. 999300US October

October 2021